

**Hertzkron**

**Advanced Static Var Generator Plus**

**User Manual**

Hertzkron | [www.hertzkron.com](http://www.hertzkron.com)

## Content

|                                                                          |    |
|--------------------------------------------------------------------------|----|
| Preface .....                                                            | 4  |
| Chapter I Safety Precautions .....                                       | 5  |
| 1.1 About This Manual .....                                              | 5  |
| 1.2 Safety Labels .....                                                  | 5  |
| 1.3 Safety Precautions .....                                             | 6  |
| Chapter II ASVG Plus Overview .....                                      | 9  |
| 2.1 Product Principle .....                                              | 9  |
| 2.2 ASVG Plus Model Definition .....                                     | 10 |
| Chapter III ASVG Plus Technical Specifications .....                     | 11 |
| Chapter IV Transportation and Storage .....                              | 13 |
| 4.1 Transportation .....                                                 | 14 |
| 4.2 Storage .....                                                        | 14 |
| 4.3 Unboxing and Inspection .....                                        | 14 |
| 4.4 Contents of the Product Packaging .....                              | 15 |
| 4.5 Accessory Packaging Contents .....                                   | 15 |
| Chapter V Installation and System Wiring Diagram .....                   | 16 |
| 5.1 Power Distribution Interface and Secondary Terminal Interface .....  | 16 |
| 5.2 Accessory Description .....                                          | 19 |
| 5.3 Primary Cable Sizing Recommendation .....                            | 19 |
| 5.4 Primary Busbar Selection Recommendation .....                        | 22 |
| 5.5 CT and Secondary Current Cable Selection Recommendation .....        | 22 |
| 5.6 Other Cable Selection Recommendation .....                           | 23 |
| 5.7 Installation and Wiring .....                                        | 24 |
| 5.7.1 Installation Environment .....                                     | 23 |
| 5.7.2 Installation Space .....                                           | 25 |
| 5.8 Installation Guidance .....                                          | 26 |
| 5.8.1 Cabinet Installation .....                                         | 26 |
| 5.8.2 Module Installation .....                                          | 26 |
| 5.9 Cable Wiring .....                                                   | 28 |
| 5.9.1 CT Installation Direction Instructions .....                       | 28 |
| 5.9.2 Single Module Single Cabinet Operating System Wiring Diagram ..... | 28 |
| 5.9.3 Multi Module Single Cabinet Operating System Wiring Diagram .....  | 29 |
| Chapter VI HMI Description (4.3-inch Touchscreen) .....                  | 29 |
| 6.1 Default Startup Interface .....                                      | 29 |
| 6.2 User Login .....                                                     | 29 |
| 6.3 Operational Permissions .....                                        | 30 |
| 6.4 Parameters Settings .....                                            | 30 |
| 6.5 Parameter Settings – System Parameters .....                         | 31 |
| 6.6 Parameter Settings – Sampling Parameters .....                       | 32 |

|                                                        |    |
|--------------------------------------------------------|----|
| 6.7 Set Harmonic Filtering Parameters .....            | 34 |
| 6.8 Parameter Settings – High Voltage Parameters ..... | 34 |
| 6.9 Operating Instructions .....                       | 35 |
| 6.10 Automatic .....                                   | 35 |
| 6.11 Manual Control (DI) .....                         | 35 |
| 6.12 Debugging Parameters .....                        | 35 |
| 6.13 Startup and DIP Switch Settings .....             | 35 |
| Chapter VII HMI Description (7-inch Touchscreen) ..... | 37 |
| 7.1 Touchscreen Installation .....                     | 37 |
| 7.1.1 Touchscreen Mounting Dimensions .....            | 37 |
| 7.1.2 Touchscreen Installation Method .....            | 38 |
| 7.1.3 Touchscreen Interface Pin Definitions .....      | 38 |
| 7.2 Default Startup Interface .....                    | 39 |
| 7.3 Module Monitoring Interface .....                  | 41 |
| 7.4 Alarm Inquiry .....                                | 43 |
| 7.5 Historical Trends .....                            | 44 |
| 7.6 Waveform Display .....                             | 45 |
| 7.7 Operational Permissions .....                      | 46 |
| 7.8 Parameter Settings .....                           | 47 |
| 7.9 System Parameters .....                            | 47 |
| 7.10 Sampling Parameters .....                         | 49 |
| 7.11 Harmonic Parameters .....                         | 50 |
| 7.12 Debugging Parameters .....                        | 51 |
| 7.13 Module Startup and DIP Switch Settings .....      | 51 |
| 7.14 Touchscreen WiFi Network Settings .....           | 52 |
| Chapter VIII ASVG Common Troubleshooting .....         | 55 |
| Chapter IX Contact Us .....                            | 56 |

## Preface

Dear Valued Customer,

Thank you for choosing the Advanced Static Var Generator Plus.

For safe and convenient use, and for proper maintenance, please read this user manual carefully before using the device and keep it handy for future reference.

Please adhere to the operating procedures and precautions that outlined in this manual.

Please neither attempt to disassemble or repair it by yourself, nor hand it over to unauthorized service departments. If the device encounters any issues. On the contrary please contact our technical service team and provide your name, address, phone number, device model, purchase date, and a description of the fault. We are dedicated to serving you.

Due to product upgrades and technological advancements, the Advanced Static Var Generator Plus may differ from the user manual. We apologize for any errors, omissions, or inconsistencies that arise.

# Chapter I Safety Precautions

## 1.1 About This Manual

- 1) This manual covers the installation and operation of the Advanced Static Var Generator Plus. Please read it carefully before installation.
- 2) Only qualified personnel are permitted to operate the equipment, which includes tasks such as installation, operation, maintenance, inspection, and dismantling. Operation by anyone other than the company's technical staff or qualified users is strictly prohibited.
- 3) Any modification, disassembly, disabling of components, or replacement of parts, may affect the safety performance of the equipment. Not using original parts may affect the working and safety performance of the equipment and will be considered as an automatic waiver of the quality guarantee.
- 4) Ensure that the equipment is properly grounded before power on. Poor grounding can cause abnormal operation and electric shock hazards.
- 5) Please wait for at least 10 minutes before disassembling the enclosure. Use a special instrument to test the DC bus voltage and ensure that the residual voltage in the DC capacitors is completely discharged before disassembling components, otherwise, there is a risk of electric shock.
- 6) Poor ventilation may cause the equipment to overheat and become damaged. Do not cover ventilation openings, and keep the equipment away from heat sources.
- 7) When transportation and storage, ensure that the equipment is not exposed to rain or water, not subjected to high temperatures, not corroded by salt fog, and not stored in a dusty environment.

## 1.2 Safety Labels

To ensure the personal and property safety of users while using this product, as well as to facilitate better product usage, this manual provides relevant information and highlights it with appropriate symbols.

The following are the symbols that may be used in this manual. Please read them carefully.



## ATTENTION

Failure to follow the requirements of this manual may result in damage or malfunction of the equipment!

---



## WARNING

Failure to follow the requirements of this manual may result in equipment damage and minor injury to personnel!



## DANGER

Failure to follow the requirements of this manual may result in serious accidents, severe injury, or death!

Whenever these symbols are used in this manual, they indicate important safety information. Failure to follow these precautions may result in economic losses, damage to this product, associated components, or enclosures, and may even lead to minor or serious injury or death. Additionally, our company assumes no responsibility for any injuries or equipment damage caused by your company or your company's clients not adhering to the contents of this manual.

### 1.3 Safety Precautions

| Before Installation |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Danger          | 1) Do not install if you find water inside the box, missing components, or noticeable damage upon unpacking .<br>2) Do not install if the packing list does not match the actual items or the ordered equipment.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <br>Attention       | 1) This equipment is intended for commercial and industrial use only and should not be used as a power source for any life-support devices.<br>2) When handling the module, ensure that you firmly hold the enclosure. Dropping it during handling may pose a risk of injury and may also damage the equipment.<br>3) Handle the module gently to avoid damaging it.<br>4) Do not use modules that are damaged or have missing parts, as this poses a risk of injury.<br>5) The device has undergone a high-voltage test before leaving the factory. Do not perform any high-voltage testing on any parts of the device without confirmation from company technical personnel. High voltage testing may damage the equipment's insulation and internal components. |

| During Installation                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Danger      | <ol style="list-style-type: none"> <li>1) Installation, maintenance, inspection, or component replacement should not be performed by individuals who are not qualified electrical professionals. Failure to do so may pose a risk of electric shock!</li> <li>2) For modification projects, when installing primary cables or current sampling secondary lines, ensure that the system is de-energized and that the surrounding area is safe for work. Failure to ensure these conditions may result in electric shock hazards and could lead to serious injury or death!</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <br>Attention   | <ol style="list-style-type: none"> <li>1) When connecting the input cables, ensure that the equipment is properly grounded. The grounding must comply with local electrical regulations.</li> <li>2) Handle the module with care during installation and avoid dropping or bumping it. Damage resulting from improper handling is not covered under the company's responsibility or warranty.</li> <li>3) When placing two or more modules in the same cabinet, ensure they are positioned correctly to guarantee effective heat dissipation. It is recommended to add cooling systems such as fans.</li> <li>4) The installation location of the module should ensure adequate ventilation. Do not obstruct the module's built-in cooling fan's air intake and exhaust vents.</li> <li>5) The installation location of the module should allow for safe maintenance and adjustment by after-sales personnel.</li> <li>6) For wall-mounted modules, install them in areas with minimal foot traffic and ensure that safety hazard labels are clearly visible.</li> <li>7) Avoid installing the module in environments with conductive dust, volatile gases, corrosive substances, or excessive salt.</li> </ol> |
| During Running                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <br>Danger    | <ol style="list-style-type: none"> <li>1) Do not open the cover after powering on. Failure to adhere to this precaution may result in electric shock and potential injury or death.</li> <li>2) Do not install or wire the equipment while it is running.</li> <li>3) Do not touch any primary or secondary terminals of the module. Doing so may pose an electric shock hazard and could result in injury or death.</li> <li>4) This equipment must be commissioned by the manufacturer or its authorized agents. Any other operation should only be carried out under the guidance of our company's after-sales engineers. Unauthorized operation is prohibited and may cause equipment damage or even result in injury or death.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <br>Attention | <ol style="list-style-type: none"> <li>1) Do not change the factory settings of the device while it is operating, as this may cause damage to the equipment.</li> <li>2) Avoid letting any objects fall into the equipment during operation. This may cause damage to the equipment.</li> <li>3) After powering on the equipment, avoid starting and stopping of the device frequently or toggling of the upstream switches frequently.</li> <li>4) Please promptly power off the device and contact our technical personnel if the equipment emits abnormal noises or displays fault information during commissioning.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

| Maintenance                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Danger</p> | <ol style="list-style-type: none"> <li>1) Do not perform maintenance or servicing on the equipment unless you have received professional training. Failure to do so may result in personal injury or equipment damage.</li> <li>2) Do not perform maintenance or servicing on the equipment while it is live. There is a risk of electric shock.</li> <li>3) Ensure that the equipment's input power is disconnected for at least 10 minutes before performing maintenance or repairs. Failure to do so may result in harm from residual charges in the capacitors.</li> <li>4) Before performing maintenance or servicing, ensure that the equipment is safely disconnected from all power sources.</li> <li>5) After replacing any parts of the equipment, parameters must be set and checked.</li> <li>6) Do not power on or operate equipment that has reported a fault or is damaged, as this may exacerbate the damage.</li> </ol> |

## Chapter II ASVG Plus Overview

### 2.1 Product Principle

The working principle of the Advanced Static Var Generator Plus (ASVG-Plus) is to connect the voltage source converter in parallel to the power grid through a filter. Its working principle is to generate corresponding IGBT drive signals by real-time detection of the load current and based on advanced reactive, harmonic and three-phase active power detection and control algorithms, so as to achieve comprehensive compensation for reactive current, harmonic current and three-phase unbalanced current.




Figure 2.1: Principle Diagram of ASVG Plus



Figure 2.2: Physical Diagram of ASVG Plus Module

## 2.2 ASVG Plus Model Definition

The model definition of the ASVG Plus is shown in Figure 2.3. The module specifications and dimensions are listed in Table 2.1, While the cabinet specifications and dimensions are listed in Table 2.2. The 3D diagrams of the ASVG Plus module are shown in Figure 2.4 and 2.5. Detailed dimension diagrams for modules for different capacity levels can be found in the respective module assembly drawings.




Figure 2.3: Model Description Schematic Diagram

Table 2.1: Module Specifications and Dimensions

| Module Model            |                              |                    |                                        |                 |
|-------------------------|------------------------------|--------------------|----------------------------------------|-----------------|
| Models                  | Compensation Capacity (kvar) | System Voltage (V) | Dimensions Width * Depth * Height (mm) | Net Weight (kg) |
| ASVG-Plus-0.22-37k/4L-W | 37                           | 220                | 760*600*241.2                          | 74              |
| ASVG Plus-0.22-50k/4L-W | 50                           | 220                | 760*600*241.2                          | 74              |
| ASVG Plus-0.4-75k/4L-W  | 75                           | 400                | 760*600*241.2                          | 74              |
| ASVG Plus-0.4-100k/4L-W | 100                          | 400                | 760*600*241.2                          | 74              |

## Chapter III ASVG Plus Technical Specifications

The technical parameters of each series of modules are shown in Table 3.1.

Table 3.1: Technical parameters of each series module

|                                                 | 220V Series                                                                                                                                                                                                    | 380V Series     |
|-------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| <b>Altitude</b>                                 | < 2000m (derated per GB/T 3859.2 above 2000m)                                                                                                                                                                  |                 |
| <b>Ambient Temperature</b>                      | -10°C ~ +50°C (derated above 40°C)                                                                                                                                                                             |                 |
| <b>Relative Humidity</b>                        | ≤ 90%, no condensation on surface at monthly min. temperature of 25°C                                                                                                                                          |                 |
| <b>Pollution Level</b>                          | Below Level III                                                                                                                                                                                                |                 |
| <b>Operating Voltage</b>                        | AC220V (±20%)                                                                                                                                                                                                  | AC380V (±20%)   |
| <b>Operating Frequency</b>                      | 50Hz/60Hz (45Hz~63Hz)                                                                                                                                                                                          |                 |
| <b>Rated Compensation Capacity</b>              | 37kvar, 50kvar                                                                                                                                                                                                 | 75kvar, 100kvar |
| <b>Power Grid Structure</b>                     | 3P3W, 3P4W                                                                                                                                                                                                     |                 |
| <b>Numbers in Parallel</b>                      | Unlimited                                                                                                                                                                                                      |                 |
| <b>System Efficiency</b>                        | ≥97%                                                                                                                                                                                                           |                 |
| <b>Switching Frequency</b>                      | 16kHz                                                                                                                                                                                                          |                 |
| <b>Function Selection</b>                       | Reactive Power, Harmonic, Reactive Power + Harmonic, Harmonic + Reactive Power, Harmonic + Unbalance, Reactive Power + Unbalance, Harmonic + Unbalance + Reactive Power, Reactive Power + Unbalance + Harmonic |                 |
| <b>Reactive Power</b>                           | ≥ 99%                                                                                                                                                                                                          |                 |
| <b>Unbalance Compensation Capacity</b>          | ≤5%                                                                                                                                                                                                            |                 |
| <b>Current Harmonic Compensation Capability</b> | ≥95%                                                                                                                                                                                                           |                 |
| <b>Full Response Time</b>                       | Reactive Power <10ms, Harmonics <40ms                                                                                                                                                                          |                 |
| <b>Neutral Line Filtering Capability</b>        | The neutral line filtering capability is 3 times that of the phase filtering capability.                                                                                                                       |                 |
| <b>Cooling Method</b>                           | Forced Air Cooling                                                                                                                                                                                             |                 |
| <b>Noise</b>                                    | ≤65dB                                                                                                                                                                                                          |                 |
| <b>Communication</b>                            | 2*RS485 Communication Ports (Supports WiFi)                                                                                                                                                                    |                 |
| <b>Protection</b>                               | Overload, Software/Hardware Over current, Over/Under voltage, Unbalance, Power Supply Fault, Over temperature, Frequency Anomaly, Short Circuit Protection, Resonance Protection                               |                 |
| <b>Overload Capacity</b>                        | 1.2 times rated overload for 60 seconds                                                                                                                                                                        |                 |
| <b>Installation</b>                             | Rack-Mounted, Wall-Mounted                                                                                                                                                                                     |                 |
| <b>Entry Line Method</b>                        | Rear Inlet (Rack-Mounted), Top Inlet (Wall-Mounted)                                                                                                                                                            |                 |

|                                      |                                                                                   |
|--------------------------------------|-----------------------------------------------------------------------------------|
| <b>Protection Level</b>              | IP20 (IP54 is customizable)                                                       |
| <b>Electromagnetic Compatibility</b> | EMC electromagnetic compatibility RE and CE tests meet Class A testing standards. |

## Chapter IV Transportation and Storage

### 4.1 Transportation

The product can be transported by automobile, train, airplane, and ship. It must be handled carefully during transportation. Exposure to rain, intense sunlight, severe vibration, collision, and inversion is strictly prohibited. The transportation temperature should be within the range of  $-40^{\circ}\text{C}$  to  $+70^{\circ}\text{C}$ .

| Sign                                                                              | Description                                                                                                              |
|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
|  | The module must be kept with the front side facing up. It is prohibited to lay the module horizontally, tilt, or invert. |
|  | Handle with care to avoid damage to the module caused by excessive collision or friction during transportation.          |
|  | Take precautions against moisture to avoid the module being exposed to rain or becoming damp.                            |

### 4.2 Storage

The product must not be exposed to direct sunlight or rain. It should be stored in a well-ventilated area where the surrounding temperature is between  $-40^{\circ}\text{C}$  and  $+70^{\circ}\text{C}$ , with a maximum relative humidity of 95% (equivalent to an air temperature of  $20\pm 5^{\circ}\text{C}$ ) and free from corrosive gases.

### 4.3 Unboxing and Inspection

Upon unboxing, please carefully check:

|                                                                                                  |                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Attention | 1) Verify that the capacity and model on the cabinet nameplate, module labels that align with your order.                                                                                                                                                                                                                                                 |
|                                                                                                  | 2) Check the contents of the box, including: equipment, user manual, product certificate, factory inspection report, six M4X10 cross-recessed flat head screws, two mounting ears, two handles (304 stainless steel, $\Phi 10*96\text{mm}$ , M5 screw holes), one each of 6P/8P/12P terminal blocks, and some accessories pre-installed on the equipment. |
|                                                                                                  | 3) If your order includes a centralized monitoring touchscreen, it is typically packaged separately. The package includes a 7-inch touchscreen, touchscreen installation accessories, communication cables for the touchscreen connection module, equipment engineering drawings, and insulation covers for module terminal blocks.                       |
|                                                                                                  | 4) Check for any damage during transportation. If you find any omissions or damage, please contact us promptly for resolution.                                                                                                                                                                                                                            |

## 4.4 Contents of the Product Packaging




Figure 4.1: Module Packaging Illustration

## 4.5 Accessory Packaging Contents

- 1) The package contains the ASVG-Plus device, a touchscreen, a user manual, a product certificate of conformity, and a factory inspection report.
- 2) Main Unit Accessories: M4x10 countersunk head screws (iron-nickel plated) x6, mounting brackets x2, handles (304 stainless steel,  $\Phi 10 \times 96$ mm, with M5 screw holes) x2, terminal blocks (6-pin x1, 10-pin x3), and a primary wiring protective cover (optional)—the latter is pre-installed on the device body.
- 3) Main Unit and Accessories (Note: Some accessories are pre-installed on the main unit body at the factory).

# Chapter V Installation and System Wiring

## Diagram

### 5.1 Power Distribution Interface and Secondary Terminal Interface

The end-user only needs to select appropriate cables based on the power requirements for connecting to the fixed terminals of the equipment. The connections for each terminal are shown in Figure 5.1 and Table 5.1.




Figure5.1: External terminal block

Table5.1: Module terminal diagram description

| Port Name                                     | Port Labeling | Function/Description                                                         |
|-----------------------------------------------|---------------|------------------------------------------------------------------------------|
| Primary Circuit<br>Equipment<br>Incoming Line | A             | L1 Phase Incoming Cable                                                      |
|                                               | B             | L2 Phase Incoming Cable                                                      |
|                                               | C             | L3 Phase Incoming Cable                                                      |
|                                               | N             | Phase N Incoming Cable (all 3 N-phases need to be wired)                     |
|                                               | N             | Phase N Incoming Cable (all 3 N-phases need to be wired)                     |
|                                               | N             | Phase N Incoming Cable (all 3 N-phases need to be wired)                     |
| X1 Terminal<br>Current                        | IA+           | Ia (Connects to S1 terminal of the A-phase CT on the grid side or load side) |

# Advanced Static Var Generator Plus User Manual\_V6.0

|                                           |       |                                                                                                                |
|-------------------------------------------|-------|----------------------------------------------------------------------------------------------------------------|
| Sampling(CT:5A)                           | IA-   | Ia (Connects to S2 terminal of the A-phase CT on the grid side or load side)                                   |
|                                           | IB+   | Ib (Connects to S1 terminal of the B-phase CT on the grid side or load side)                                   |
|                                           | IB-   | Ib (Connects to S2 terminal of the B-phase CT on the grid side or load side)                                   |
|                                           | IC+   | Ic (Connects to S1 terminal of the C-phase CT on the grid side or load side)                                   |
|                                           | IC-   | Ic (Connects to S2 terminal of the C-phase CT on the grid side or load side)                                   |
|                                           | DI1+  | Start signal+                                                                                                  |
|                                           | DI1-  | Start signal-                                                                                                  |
|                                           | DI2+  | Emergency stop signal+                                                                                         |
|                                           | DI2-  | Start Signal-                                                                                                  |
| X6 Terminal<br>Current<br>Sampling(CT:5A) | IA_D+ | Ia (Connect to the S1 terminal of the A-phase CT in this cabinet, if applicable based on the actual situation) |
|                                           | IA_D- | Ia (Connect to the S2 terminal of the A-phase CT in this cabinet, if applicable based on the actual situation) |
|                                           | IB_D+ | Ib (Connect to the S1 terminal of the B-phase CT in this cabinet, if applicable based on the actual situation) |
|                                           | IB_D- | Ib (Connect to the S2 terminal of the B-phase CT in this cabinet, if applicable based on the actual situation) |
|                                           | IC_D+ | Ic (Connect to the S1 terminal of the C-phase CT in this cabinet, if applicable based on the actual situation) |
|                                           | IC_D- | Ic (Connect to the S2 terminal of the C-phase CT in this cabinet, if applicable based on the actual situation) |
| X3 Terminal<br>Communication<br>Interface | GND   | Power output negative pole 0V (power supply for human-machine interface and indicator light)                   |
|                                           | GND   | Power output negative pole 0V (power supply for human-machine interface and indicator light)                   |
|                                           | +24V  | Power output positive +24V (power supply for human-machine interface)                                          |
|                                           | DO3   | Fault indication, output +24V voltage(Generates a voltage                                                      |

# Advanced Static Var Generator Plus User Manual\_V6.0

|                                   |       |                                                                                                                                                                                                                                                           |
|-----------------------------------|-------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                   |       | relative to GND to light up the lamp)                                                                                                                                                                                                                     |
|                                   | DO4   | Ready indication, output +24V voltage(Generates a voltage relative to GND to light up the lamp)                                                                                                                                                           |
|                                   | DO5   | Running indication, output +24V voltage(Generates a voltage relative to GND to light up the lamp)                                                                                                                                                         |
|                                   | 485A1 | Communicate with the human-machine interface or with the previous module                                                                                                                                                                                  |
|                                   | 485B1 | Communicate with the human-machine interface or with the previous module                                                                                                                                                                                  |
|                                   | GND   | Power output negative pole 0V (power supply for human-machine interface and indicator light)                                                                                                                                                              |
|                                   | +24V  | Power output positive +24V (power supply for human-machine interface)                                                                                                                                                                                     |
| X2 Terminal<br>Control and Signal | A     | Reserved interface                                                                                                                                                                                                                                        |
|                                   | B     | Reserved interface                                                                                                                                                                                                                                        |
|                                   | Z     | Reserved interface                                                                                                                                                                                                                                        |
|                                   | Y     | Reserved interface                                                                                                                                                                                                                                        |
|                                   | 4851A | Communicate with the next module                                                                                                                                                                                                                          |
|                                   | 4851B | Communicate with the next module                                                                                                                                                                                                                          |
|                                   | CANH  | Reserved interface                                                                                                                                                                                                                                        |
|                                   | CANL  | Reserved interface                                                                                                                                                                                                                                        |
|                                   | 4852A | Debug port                                                                                                                                                                                                                                                |
|                                   | 4852B | Debug port                                                                                                                                                                                                                                                |
| Binary Dip Switch                 | 1D1   | Set the module communication address ("1" represents "off", "0" represents "on"). The bit weight from left to right is: 128. The sum of each dial value is the module address. A touch screen can connect up to 8 modules, and the address is set to 1~8. |
|                                   | 1D2   |                                                                                                                                                                                                                                                           |
|                                   | 1D3   |                                                                                                                                                                                                                                                           |
|                                   | 1D4   |                                                                                                                                                                                                                                                           |
| X4 Terminal                       | LAN   | Network cable interface                                                                                                                                                                                                                                   |
| X5 Terminal                       | WiFi  | Wi-Fi interface                                                                                                                                                                                                                                           |
| Grounding                         | PE    | System grounding terminal. Because the system casing is a                                                                                                                                                                                                 |

|                                                                                                |                                                                            |                                                                                                                                                                     |
|------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                |                                                                            | metal casing, in order to prevent accidents that endanger personal safety, it must be connected to the ground through this terminal before the system is turned on. |
| <br>Attention | <p>Note:</p> <p>The maximum allowable secondary current for CTs is 5A.</p> |                                                                                                                                                                     |

## 5.2 Accessory Description

Table 5.2: Accessories Description

| Accessory Name                                    | Installation Location                                                                                                                                                                                                                                                                                                  | Function Description                                                                                                                                                                                                                 | Selection Recommendations                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Molded Case Circuit Breaker (MCCB)<br>(Mandatory) | <ol style="list-style-type: none"> <li>Power input terminal of the module.</li> <li>For rack-mounted modules, the circuit breaker is installed inside the cabinet.</li> <li>For wall-mounted modules, the circuit breaker is installed inside the distribution box that comes with the wall-mounted module.</li> </ol> | <ol style="list-style-type: none"> <li>Control the module's power on/off.</li> <li>Provides overload, short circuit, and under-voltage protection, safeguarding both the wiring and the module from damage.</li> </ol>               | <ol style="list-style-type: none"> <li>Typically, one molded case circuit breaker is configured per module, but multiple modules can also be protected by a single larger molded case circuit breaker.</li> <li>The rated current of the molded case circuit breaker should be selected at 1.25 to 1.5 times the rated current of the module. Choose between 3-pole or 4-pole types.</li> </ol> |
| Surge Protection Device (SPD)<br>(Optional)       | <ol style="list-style-type: none"> <li>Power input terminal of the module, connected to the upper terminal of the molded case circuit breaker.</li> <li>Installed inside the cabinet or within the distribution box.</li> </ol>                                                                                        | Provides safety protection for the cabinet and modules. When surge voltages occur in the electrical circuit, the surge protection device can conduct and divert the surge in a very short time, thereby preventing over-voltage from | <ol style="list-style-type: none"> <li>Poles: 3P+N</li> <li>Maximum discharge current: 40kA and above</li> </ol>                                                                                                                                                                                                                                                                                |

# Advanced Static Var Generator Plus User Manual\_V6.0

|                                            |                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                 |                                                                                                         |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
|                                            |                                                                                                                                                                                                                          | damaging other equipment in the electrical circuit.                                                                                                                                                                                                             |                                                                                                         |
| Miniature Circuit Breaker (MCB) (Optional) | <ol style="list-style-type: none"> <li>1) Surge protection device or fan input terminal.</li> <li>2) Installed inside the cabinet or within the distribution box.</li> </ol>                                             | <p>The purpose of installing an isolating switch before the surge protection device or fan is primarily to prevent fire hazards, such as burning, in the event of a sustained short circuit fault within the surge protection device's internal components.</p> | <ol style="list-style-type: none"> <li>1) Rated current: 20A and above</li> <li>2) Poles: 4P</li> </ol> |
| Central Monitoring Screen (Mandatory)      | <ol style="list-style-type: none"> <li>1) It can be mounted on the cabinet door for cabinet-mounted installations.</li> <li>2) It can be mounted on the distribution box door for wall-mounted installations.</li> </ol> | Centralized monitoring facilitates viewing and setting parameters.                                                                                                                                                                                              | Factory-supplied accessories                                                                            |
| Emergency Stop Button (Optional)           | Installed on the cabinet door or the distribution box door.                                                                                                                                                              | <p>The emergency stop switch can be pressed immediately to stop the module from operating, effectively protecting it if an abnormal situation occurs inside the cabinet or module (such as smoke, unusual noises, or sparks).</p>                               | Release type button                                                                                     |

|                                            |                                                                                             |                                                                                                                                                                 |                                                                                                                                                                         |
|--------------------------------------------|---------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fan<br>(Mandatory)                         | Installed on the rear cabinet door of the cabinet                                           | 1) It is recommended to install 2 fans when the number of modules is $\leq 2$ .<br>2) It is recommended to install 4 fans when the number of modules is $> 2$ . | 1) AC 220V 50Hz<br>2) 87W and above<br>3) Airflow: 850 CFM<br>4) Rotation direction: Counterclockwise                                                                   |
| Status Indicator<br>(Optional)             | 1) Installed on the cabinet door.<br>2) Connected to the circuit at the alarm output point. | Displays the statuses of the module, including running, stopping, normal, and fault conditions.                                                                 | 1) Any color<br>2) Head diameter: 22mm                                                                                                                                  |
| Relay<br>(Optional)                        | Installed inside the cabinet.                                                               | Controls the indicator light and fan                                                                                                                            | Do not connect DI/DO circuits for multiple modules in parallel.                                                                                                         |
| Current Transformer<br>(CT)<br>(Mandatory) | Installed on the main busbar of the distribution system.                                    | Measures the load current of the distribution system.                                                                                                           | 1) The secondary current must be 5A, with a range of 100/5 to 10000/5 available for selection.<br>2) Accuracy of 0.5 or better.<br>3) Rated burden of 2.5 VA or higher. |

### 5.3 Primary Cable Sizing Recommendation

The selection of ASVG Plus incoming cables for different capacities and current ratings should comply with electrical regulations and consider environmental conditions. The following table can be used as a reference:

Table5.3: Recommended cable cross-section values

| Primary Power Cable |                                                      |                               |                                |
|---------------------|------------------------------------------------------|-------------------------------|--------------------------------|
| Capacity<br>(kvar)  | Three-Phase Main Circuit Input<br>(mm <sup>2</sup> ) | N Cable<br>(mm <sup>2</sup> ) | PE Cable<br>(mm <sup>2</sup> ) |
| 75                  | 35                                                   | 35 × 2                        | 25                             |
| 100                 | 50                                                   | 50 × 2                        | 35                             |

|                                                                                                |                                                                                                                                                                |                |     |
|------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|-----|
| 200                                                                                            | 95                                                                                                                                                             | $95 \times 2$  | 70  |
| 300                                                                                            | 150 or 2 x 70                                                                                                                                                  | 150 or 2 x 70  | 120 |
| 400                                                                                            | 185 or 2 x 95                                                                                                                                                  | 185 or 2 x 95  | 150 |
| 500                                                                                            | 240 or 2 x 120                                                                                                                                                 | 240 or 2 x 120 | 185 |
| 600                                                                                            | 300 or 2 x 150                                                                                                                                                 | 300 or 2 x 150 | 240 |
| <br>Attention | 1) ASVG Plus is rated in kvar, with the conversion factor of $1 \text{ kvar} \approx 1.5\text{A}$ .<br>The specifications in the table are for reference only. |                |     |
|                                                                                                | 2) Cables are typically selected as BVR multi-strand copper core PVC insulated flexible wires.                                                                 |                |     |
|                                                                                                | 3) If using aluminum cables, ensure they correspond to the appropriate current-carrying capacity specifications for copper wires.                              |                |     |

## 5.4 Primary Busbar Selection Recommendation

Table5.4: Copper Medal Selection Reference

| Capacity (kvar) | Busbar Specifications (mm*mm) |
|-----------------|-------------------------------|
| <100            | 15 x 3                        |
| 100~200         | 30 x 4                        |
| 200~400         | 50 x 5                        |
| 400~600         | 60 x 8                        |

## 5.5 CT and Secondary Current Cable Selection Recommendation

The current transformer is primarily used in ASVG Plus to measure load current and calculate data such as harmonic current, reactive current, negative sequence current, and zero-sequence current.

The following table can be used as a reference:

Table 5.5: CT Cable Selection Recommendation

| Parameter               | Specification Requirements | Remarks                                                                                                      |
|-------------------------|----------------------------|--------------------------------------------------------------------------------------------------------------|
| Primary Rated Current   | —                          | 1.5 times the actual maximum operating current in the system $\leq$ Primary Rated Current of the Transformer |
| Secondary Rated Current | 5A                         | —                                                                                                            |
| Rated Voltage           | $\geq 0.66\text{kV}$       | —                                                                                                            |
| Rated Capacity          | $\geq 2\text{VA}$          | —                                                                                                            |
| Accuracy Class          | Class 0.5 or Class 0.2     | —                                                                                                            |

|               |                                                                                                                                    |                                                                                       |
|---------------|------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Size          | ——                                                                                                                                 | Specific dimensions should be selected based on the on-site installation environment. |
| Wire Diameter | Three sets (six wires) of cables on the secondary side of the transformer (rated current 5A). Wire diameter: 2.5 mm <sup>2</sup> . |                                                                                       |

## 5.6 Other Cable Selection Recommendation

Table 5.6: Other Cable Selection Recommendation Table

| Name                                       | Specification                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Surge Protector Primary Wiring             | 6mm <sup>2</sup> BVR Multi-strand Copper Core Flexible Wire                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Fan Circuit Wiring                         | 1.5mm <sup>2</sup> BVR Multi-strand Copper Core Flexible Wire.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Emergency Stop Switch Circuit Wiring       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Indicator Light Circuit Wiring             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Grounding Cable                            | <p>Yellow-green BVR multi-strand copper-core flexible wire:</p> <p>Protective grounding PE Wire Selection Recommendation:</p> <p>If the cross-sectional area of the AC phase conductor is less than 16mm<sup>2</sup>, select a grounding wire with the same cross-sectional area as the phase conductor.</p> <p>If the cross-sectional area of the phase conductor is between 16mm<sup>2</sup> and 35mm<sup>2</sup> (inclusive), choose a 16mm<sup>2</sup> grounding wire.</p> <p>If the cross-sectional area of the phase conductor exceeds 35mm<sup>2</sup>, select a grounding wire with a cross-sectional area equal to half of the phase conductor.</p> |
| Touchscreen Communication Cable            | <p>Power Cable: 1.0mm<sup>2</sup> BVR multi-strand copper-core flexible wire (pre-installed by the factory).</p> <p>Communication Cable: Standard plug-in cable provided by our company with the equipment.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Module Interconnection Communication Cable | For communication cables, it is recommended to use RVVP 2*0.75mm <sup>2</sup> shielded wire.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

## 5.7 Installation and Wiring

### 5.7.1 Installation Environment

Table 5.7: Installation Environment

| Installation Environment Requirements                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Attention | 1) Ambient Temperature: The surrounding environment temperature significantly affects the lifespan of the ASVG Plus. The operating temperature of the ASVG Plus must not exceed the allowed range (-10°C to 50°C). If the temperature falls below -10°C, appropriate heating equipment should be added; if the temperature exceeds 45°C, cooling and ventilation equipment, such as air conditioning, should be installed. |
|                                                                                                | 2) The ASVG Plus should be mounted on a flame-retardant surface, with sufficient space around it for heat dissipation, as it generates a significant amount of heat during operation.                                                                                                                                                                                                                                      |
|                                                                                                | 3) Install in a location with minimal vibration. Vibration should not exceed 0.6G. Pay special attention to avoid locations near stamping or punching equipment.                                                                                                                                                                                                                                                           |
|                                                                                                | 4) Avoid installing in areas with direct sunlight, high humidity, or water droplets.                                                                                                                                                                                                                                                                                                                                       |
|                                                                                                | 5) Avoid installation in areas with corrosive, flammable, or explosive gases.                                                                                                                                                                                                                                                                                                                                              |
|                                                                                                | 6) Avoid installation in locations with oil contamination or dust.                                                                                                                                                                                                                                                                                                                                                         |
|                                                                                                | 7) The installation environment must not be subjected to strong magnetic fields, nuclear radiation, or high-power RF interference.                                                                                                                                                                                                                                                                                         |
|                                                                                                | 8) When installing rack-mounted modules in a cabinet, ensure the cabinet meets relevant standards and regulations.                                                                                                                                                                                                                                                                                                         |
|                                                                                                | 9) Wall-mounted modules should be installed in areas with minimal foot traffic and must have prominent safety labels.                                                                                                                                                                                                                                                                                                      |
|                                                                                                | 10) The wall-mounted installation location must be on a dry wall.                                                                                                                                                                                                                                                                                                                                                          |
|                                                                                                | 11) The module is cooled by an internal fan with intelligent air cooling. Ventilation openings must remain unobstructed during operation. To prevent dust from clogging the intake, regularly clean the intake openings; it is recommended to clean them every three months.                                                                                                                                               |

## 5.7.2 Installation Space

Table 5.8: Installation Space Requirements

| Installation Space Requirements                                                                |                                                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Attention | 1) Do not obstruct the module's air vents.                                                                                                                                                                                                                                            |
|                                                                                                | 2) For floor-standing installations, leave at least 600mm of clearance for airflow at the front and rear of the cabinet, and ensure there is sufficient space for maintenance behind the cabinet. Additionally, ensure that the rear door of the cabinet can open and close properly. |
|                                                                                                | 3) For wall-mounted installations, leave at least 150mm of clearance above and below the module for proper airflow.                                                                                                                                                                   |
|                                                                                                | 4) The wall-mounted installation should be positioned at least 1.5 meters above the ground and have a clearly visible electrical hazard warning label.                                                                                                                                |

Rack-Mounted Installation Space Requirements:




Figure 5.2: Floor-Standing Installation Space Requirements Diagram

## Wall-Mounted Installation Space Requirements:




Figure 5.3: Wall-Mounted Installation Space Requirements Diagram

## 5.8 Installation Guidance

### 5.8.1 Cabinet Installation




Figure 5.4: 600k Cabinet Installation Diagram

### 5.8.2 Module Installation

The ASVG Plus module is available in both wall-mounted and rack-mounted versions. The main dimensions of both the wall-mounted and rack-mounted models are identical, excluding

protruding parts such as structural components and handles used for mounting.

**Wall-Mounted Installation:**

The wall-mounted module can be installed on the wall for independent operation. The mounting hole positions are shown in Figures 5.5.

**Installation Method:**

Use six mounting holes in the bracket and secure the module to the wall or cabinet using M8\*15 cross-recessed combination screws.




Figure 5.5: Wall-mounted ASVG Plus installation hole diagram

**Rack-Mount Installation:**

When mounting the module in the rack, the location of the installation holes is as shown in Figure 5.6.

**Installation Method:**

Secure the module to the rack using the 4 mounting holes on the bracket with M6\*15 cross-slot combination screws.




Figure 5.6: Rack-Mounted ASVG Plus Installation Diagram

## 5.9 Cable Wiring

### 5.9.1 CT Installation Direction Instructions




Figure 5.7: CT Installation Diagram

|                                                                                                       |                                                                                                                             |
|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| <br><b>Attention</b> | <p>S1 should be the positive (+) and S2 should be the negative (-) if the current direction of the CT is from P1 to P2.</p> |
|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|

### 5.9.2 Single Module Single Cabinet Operating System Wiring Diagram

When operating with a single module in a single cabinet, the field-sampling CT (CT1 in Figure 5.8) should be installed on the load side as shown in Figure 5.8. The field-sampling CT can also be installed on the power side.




Figure 5.8: System Wiring Diagram for Single Module Operation in a Single Cabinet

### 5.9.3 Multi Module Single Cabinet Operating System Wiring Diagram

When multiple ASVG Plus modules are connected in parallel to increase compensation current, all the devices share a single set of current transformers. The current signals collected by the external current transformers are sent to all the parallel ASVG Plus devices. Additionally, an extra set of sampling current transformers (CT2) is installed inside the cabinet to measure the total cabinet current. The on-site CT is installed on the power side, as shown in Figure 5.9.




Figure 5.9: Multi Module Single Cabinet Operating System Wiring Diagram

# Chapter VI HMI Description (4.3-inch Touchscreen)

## 6.1 Default Startup Interface

The main screen of the touchscreen is shown in Figure 6.1. It displays various system information, including details information of each side (grid and load). On the main screen, end-user can start, stop, and reset the device. On the left side of the main screen are the tabs for "Data", "Settings" and "Records".




Figure 6.1: HMI Main Page

## 6.2 User Login

The login page is shown in Figure 6.2. It will pop up when you click the "Settings" button or update system parameters. Default password is 123.




Figure 6.2: Login Page

### 6.3 Operational Permissions

Users can perform operations such as querying and configuring parameters, querying runtime data, accessing historical records, starting, stopping, and resetting.

### 6.4 Parameters Settings

Select the 'Settings' button on the main touchscreen interface to enter the parameter settings page, as shown in Figure 6.3. All parameters are categorized into different sections, including 'System Parameters', 'Sampling Parameters', 'High Voltage Parameters', 'Harmonic Controller', 'Single Parameters' and 'Time Calibration'. Click on the corresponding tab to access the parameter settings page for any specific parameter.




Figure 6.3: Parameter Settings Interface

### 6.5 Parameter Settings – System Parameters

The system parameter settings interface is shown in Figure 6.4. This section provides a detailed explanation of the parameters in this interface.




Figure 6.4: System Parameter Settings

- 1) Number of Parallel Modules: The total number of ASVG modules connected in parallel. If two modules are connected in parallel, set this value to 2.
- 2) Cabinet Capacity: The sum of the capacities of all modules connected in parallel within this cabinet (setting unit: kvar). For example, if this cabinet contains two modules with individual capacities of 75 kvar and 100 kvar, set this value to 175.

- 3) Compensation Mode Selection: Options include Reactive Power, Harmonic, Reactive Power + Harmonic, Harmonic + Reactive Power, Harmonic + Three-Phase Unbalance, Reactive Power + Three-Phase Unbalance, Harmonic + Three-Phase Unbalance + Reactive Power, Reactive Power + Three-Phase Unbalance + Harmonic, and Self-Aging. Different priority levels can be selected for these modes; the "Self-Aging" mode should be used with caution.
- 4) DI Start/Stop Enable: If the customer requires the module to be started via an external switch, select "Enable"; otherwise, select "Disable."
- 5) Auto-Start Enable: If set to "Disable," the module will only start after a user manually presses the "Start" button following power-up. If set to "Enable," the module will automatically start once the specified conditions are met after power-up.
- 6) Power Factor Setpoint: The target power factor value for the site, which can be set within the range of 0 to 1.
- 7) After configuring all parameters, click the "Save" button to confirm and finalize the settings. You may click the "Query" button to verify whether the settings have been successfully applied.

## 6.6 Parameter Settings – Sampling Parameters

The sampling parameters setting interface is shown in Figure 6.5, and the parameters on this interface are explained in detail.

| Sampling Parameter               |              |
|----------------------------------|--------------|
| Sampling Input Current Location  | [Dropdown]   |
| Sampling Input Current Direction | [Dropdown]   |
| Input CT Ratio                   | [Text Input] |
| Sampling Load Current            | [Dropdown]   |
| Sampling Load Current Location   | [Dropdown]   |
| Sampling Load Current Direction  | [Dropdown]   |
| Load CT Ratio                    | [Text Input] |

Save Query

Figure 6.5: Sampling Parameters Setting Interface

- 1) Input Current Sampling Position Selection: If the field CT is connected on the incoming line side, select "Grid Side"; if the field CT is connected on the load side, select "Load Side."
- 2) Input Current Sampling Direction Selection: If the direction of the field CT points from the load side toward the grid side, select "Flowing into Grid"; otherwise, select "Flowing out of Grid."

- 3) Input Current CT Ratio: If the field CT ratio is 2000:5, set the value to "400." Device Current Sampling Enable: This sampling function is used exclusively for whole-cabinet current sampling. If the cabinet contains more than one module, it is recommended that the modules be connected to the cabinet's dedicated sampling CT; if connected, select "Enable"; otherwise, select "Disable."
- 4) Device Current Sampling Position Selection: This sampling function is used exclusively for whole-cabinet current sampling; select "Cabinet."
- 5) Device Current Sampling Direction Selection: If the direction of the whole-cabinet sampling CT points from the module side toward the busbar side, select "Flowing into Grid"; otherwise, select "Flowing out of Grid."
- 6) Device Current CT Ratio: If the whole-cabinet sampling CT ratio is 2000:5, set the value to "400."

## 6.7 Set Harmonic Filtering Parameters

The harmonic filtering interface is shown in the figure 6.6. If harmonic filtering is required for the application, you can set the compensation level for the specified harmonic orders. To filter the 3rd harmonic, click the second tile corresponding to the 3rd harmonic in rows 2 through 8, set the filtering level (e.g., from 0.95 to 95%), then click "Save" and "Query" to confirm. The device allows you to filter up to 8 selected harmonics.




Figure 6.6: Harmonic Filter Parameter Settings Interface

## 6.8 Parameter Settings – High Voltage Parameters

The high voltage parameter settings interface is shown in Figure 6.7, with a detailed explanation of the parameters provided.

| Parameter              | Value        |
|------------------------|--------------|
| Winding Type 1         | [Dropdown]   |
| Transformation Ratio 1 | [Text Input] |
| Winding Type 2         | [Dropdown]   |
| Transformation Ratio 2 | [Text Input] |

Buttons: Save, Query

Figure 6.7: High Voltage Parameter Settings Interface

- 1) Winding Type: You can choose from Normal, YY0, DY11, or YD1.
- 2) Transformation Ratio: If the on-site transformation ratio is 10kV:0.4kV, set the value to "25".

## 6.9 Operating Instructions

The equipment's operating modes can be classified into automatic operation and DI operation, and can be configured according to actual requirements.

### 6.10 Automatic

Auto-start Enable: Select "Disabled" to require manual clicking of the Start button to initiate the ASVG cabinet. Set to "Enabled" to allow the ASVG to start automatically after power-up, provided that the device's auto-start conditions are met.

### 6.11 Manual Control (DI)

DI Start/Stop Enable: If the customer requires the ASVG device to be started via an external switch, please select "Enable" for this setting; otherwise, select "Disable."

**Note:** Any parameter modifications must be determined by qualified technical personnel; please proceed with caution when making changes.

### 6.12 Debugging Parameters

The debugging parameters pertain to the manufacturer's debugging interface and are not accessible to the public.

### 6.13 Startup and DIP Switch Settings

When two or more modules are connected in parallel, the DIP switches must be configured. The module with Address 1 corresponds to Module 1 on the touchscreen; the module with Address 2 corresponds to Module 2 on the touchscreen; and so on.







| machine number | DIP switch settings                                                               | machine number | DIP switch settings                                                               | machine number | DIP switch settings                                                                | machine number | DIP switch settings                                                                 |
|----------------|-----------------------------------------------------------------------------------|----------------|-----------------------------------------------------------------------------------|----------------|------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------|
| 1              |  | 2              |  | 3              |  | 4              |  |
| machine number | DIP switch settings                                                               | machine number | DIP switch settings                                                               | machine number | DIP switch settings                                                                | machine number | DIP switch settings                                                                 |
| 5              |  | 6              |  | 7              |  | 8              |  |

Figure 6.8 : DIP Switch Configuration Diagram

After powering on the equipment, use the "**Module Switching Configuration**" interface to enable the specific modules required to establish a communication link with the touchscreen. Once the communication link has been successfully established, proceed to configure the operating parameters. Provided that the parameters are set correctly and no faults are detected, the "Start Enable" indicator on the touchscreen will illuminate; at this point, the "Start" button becomes active (enabled), while the "Stop" button remains inactive (disabled). On the Module Monitoring interface, select the specific module you wish to start, then click the "Start" button to initiate the equipment startup sequence; the DC bus voltage will subsequently rise. When multiple modules are connected in parallel, the startup procedure for the remaining modules follows a similar process.

When two or more modules are connected in parallel, the procedure for shutting down the system via the touchscreen is as follows: When the "Start" button appears inactive (disabled) and the "Stop" button appears active (enabled), simply click the "Stop" button to shut down the equipment.





Notice

Parameter modifications must be determined by professional technical personnel, please proceed with caution.

## Chapter VII HMI Description (7-inch Touchscreen)

### 7.1 Touchscreen Installation

#### 7.1.1 Touchscreen Mounting Dimensions



7.1.2 Touchscreen Installation Method




Figure 7.3: Touchscreen Installation Method

7.1.3 Touchscreen Interface Pin Definitions




Figure 7.4: Touchscreen Interface Pin Definitions

Table 7.1: Touchscreen Serial Port DB9 Pin Definitions

| Touchscreen Serial Port DB9 Pinout                                                  |                                 |      |        |
|-------------------------------------------------------------------------------------|---------------------------------|------|--------|
|  | COM1<br>Connects to Modules 1~4 | PIN7 | RS485+ |
|                                                                                     |                                 | PIN8 | RS485- |
|                                                                                     | COM2<br>Connects to Modules 5~8 | PIN4 | RS485+ |
|                                                                                     |                                 | PIN9 | RS485- |

Table 7.2: Communication Harness and Module Wiring Reference Table

| Communication Wire Harness | SVG Module Terminals | directions                                   |
|----------------------------|----------------------|----------------------------------------------|
| COM1:485A                  | 485A1(Module 1)      | Modules 1 through 4 are connected to Link 1. |
| COM1:485B                  | 485B1(Module 1)      |                                              |
| COM2:485A                  | 485A1(Module 5)      | Modules 5 through 8 are connected to Link 2. |
| COM2:485B                  | 485B1(Module 5)      |                                              |

## 7.2 Default Startup Interface

Upon power-up, the touchscreen defaults to the "Home" interface. From this interface, users can view real-time system operating data, such as grid voltage, grid current, device current, active power, reactive power, and apparent power. Specifically, the "device current" refers to the total compensation current of the ASVG cabinet, while the remaining data points represent grid-side parameters.




Figure 7.5: Default Startup Interface

The homepage not only displays real-time runtime data but also allows you to navigate to specific sub-interfaces by clicking icon buttons, as shown in the figure below:




Figure 7.6: Startup Default Interface Navigation Button (Home Button)

- ① Clicking the "🏠" icon button on the homepage allows you to navigate to the detailed system operational data monitoring interface; clicking the "Home" button in the top-left corner allows you to return to the previous screen.




Figure 7.7: System Operation Data Monitoring Interface

② By tapping the "  " icon button on the Home screen, you can navigate to the "Module Switching Settings and Confirmation" interface. You can return to the previous screen by tapping the "Home" button in the top-left corner or the "Back" button in the bottom-right corner.

Through this interface, users can control the communication connection status between each module and the touchscreen. The touchscreen features a "memory" function; therefore, if the device experiences an abnormal power outage and is subsequently powered back on, manual re-engagement is not required.

- 1) ID: The module sequence numbers are fixed, starting from 1; a single touchscreen can connect to a maximum of 8 modules.
- 2) ID Setting: Enter the actual communication address of the module (controlled by the module's physical DIP switches).
- 3) Module Disconnect: The touchscreen terminates communication with the specified module.
- 4) Module Connect: The touchscreen establishes communication with the specified module.




Figure 7.8: Module Switching Settings and Confirmation Interface

③ By clicking the "  " icon button located in the top-right corner of the homepage, you can navigate to the "Harmonic Bar Chart" interface. Users can select the specific harmonics they wish to view by utilizing the Module ID and the selection box on the right. Clicking the "Home" button in the top-left corner allows you to return to the previous screen.

1) This interface displays the harmonic content of the grid voltage, grid current, load current, and device current (module current). The buttons located at the top allow for switching between the harmonic display interfaces for Phases A, B, and C.

2) Display options are available for user selection in the upper-right corner of the interface. When "Device Current" is selected as the displayed content, the Module ID becomes active, allowing

users to view the "Device Current" for different modules by specifying the ID number; for all other selected options, the Module ID is not applicable.




Figure 7.9: Harmonic Bar Chart

### 7.3 Module Monitoring Interface

The module monitoring interface displays various information regarding the module, including parameters such as the current, voltage, IGBT temperature, and frequency of the individual module. Located in the bottom-right corner of the touchscreen is a status indicator displaying the communication link between the module and the touchscreen; a green indicator signifies that the module is online, while a red indicator signifies that it is offline (this status display is active only when the "Module Switching" function is engaged; it is inactive when the module is switched out).

Users can view operational data for different modules by utilizing the "Module 1" through "Module 8" toggle buttons located at the top of the interface. Additionally, users may employ the "Reset" button to reset a module (in the event of an equipment fault, an engineer must first inspect and troubleshoot the issue; once external troubleshooting has been completed, the module can be reset by pressing the "Reset" button).

**Note:** When a module fault occurs, the interface displays only the Reset button; when the module is running, it displays only the Stop button; and when the module is in standby mode, it displays only the Start and Reset buttons (however, if an external phase sequence anomaly is detected, the Start button will not be displayed, and an alarm will be triggered).




Figure 7.10: Module Monitoring Interface

## 7.4 Alarm Inquiry

The Alarm Query interface comprises "Real-time Alarms" and "Historical Alarms." The Real-time Alarms section displays the device's most recent alarm records, while the Historical Alarms interface allows users to query alarm information by specifying a specific time period.




Figure 7.11: Real-time Alarm Information Query




Figure 7.12: Historical Alarm Information Query

## 7.5 Historical Trends

The "Data Curves" interface allows you to query historical data, including historical records for grid voltage, grid current, and IGBT temperature.

The curve display interface presents data spanning the 24-hour period immediately preceding the moment the interface is accessed. To determine the absolute time for a specific point, tap on the curve displayed on the screen; an information window will then appear as shown below:

|  | Content        | Coordinate range | Current value | Unit |
|--|----------------|------------------|---------------|------|
|  | Absolute clock | 1Day             | 19:21         |      |
|  | Line1          | 0.0~500.0        |               | V    |
|  | Line2          | 0.0~500.0        |               | V    |
|  | Line3          | 0.0~500.0        |               | V    |

Figure 7.13: Curve Data Information Display

Pressing the "double-arrow" movement button below shifts the timeline by 12 hours, while the "single-arrow" button shifts it by 6 hours.

The query time range can be configured using Button . By selecting the "Specified Time" option, you can retrieve data curves for a designated time interval; the other options need not be utilized.




Figure 7.14: Grid Voltage History Curve Interface

The "Set time range" dialog box allows users to select a time range for the historical curve query. It includes the following options:

- ☐ Recent time: A dropdown menu showing "1" and a unit selector set to "Hour".
- ☐ Fixed time: A dropdown menu showing "Today".
- Time division point: A text input field showing "0" and a unit selector set to "Hour".
- ☒ Given time: A date and time selection interface with fields for Year (2026), Month (3), Day (5), Hour (13), Minute (36), and Second (29).

Buttons for "Ok" and "Cancel" are located on the right side of the dialog.

Figure 7.15: Historical Curve Query

### 7.6 Waveform Display

The waveforms include the grid voltage curve and the device current curve; the horizontal axis, ranging from 0 to 30, represents 30 waveform recording data points.




Figure 7.16: Waveform Curve

## 7.7 Operational Permissions

The permission login interface is shown in the figure below; this interface appears when you click the "Parameter Settings" button or select a parameter number. Select "User2," enter the password "123," and click the "Login" button.




Figure 7.17: Permissions Login Interface

### 1) Operational Permissions

Under this permission level, users can perform parameter queries, runtime data queries, and historical record queries, as well as operations such as startup, shutdown, and reset.

### 2) Set Permissions

Under this permission level, users can not only perform all operations authorized by their operational privileges but also configure relevant runtime parameters.

## 7.8 Parameter Settings

Select the "Parameter Settings" button on the touchscreen's main interface to access the Parameter Settings screen. All parameters are categorized into distinct groups — including "System Parameters," "Sampling Parameters," "Harmonic Parameters," and "Debugging Parameters" — which can be configured to suit actual operating conditions. To configure a specific parameter, simply tap the corresponding entry to enter its dedicated settings interface.




Figure 7.18: Parameter Settings Interface

## 7.9 System Parameters

Detailed Explanation of the System Parameter Settings Interface:





Figure 7.19: Parameter Settings Interface (Page 1)

- 1) Number of Parallel Modules: The total count of all ASVG modules contained within the cabinet. For example, if the cabinet houses three modules, set this value to 3.
- 2) Number of Parallel Cabinets: The total count of cabinets operating in parallel. For example, if three cabinets are connected in parallel, set this value to 3.
- 3) Reactive Capacity Ratio (This Cabinet): The ratio of this specific cabinet's reactive capacity to the total reactive capacity of all cabinets in the system. For instance, if three cabinets have capacities of 100 kvar, 200 kvar, and 300 kvar respectively, the parameter for the first cabinet would be  $100/600$ ; therefore, set the value to 0.167.
- 4) Harmonic Capacity Ratio (This Cabinet): The ratio of this specific cabinet's harmonic capacity to the total harmonic capacity of all cabinets in the system. The configuration method is identical to that used for the Reactive Capacity Ratio.
- 5) Cabinet Capacity (kvar): The total capacity of the modules contained within this cabinet. For example, if the cabinet contains three 100-kvar modules and one 75-kvar module, set this value to 375.
- 6) Once the parameter settings on this interface are complete, you must click on the specific parameter fields located beneath the list — namely: "Number of Parallel Modules," "Number of Parallel Cabinets," "Reactive Capacity Ratio (This Cabinet)," "Harmonic Capacity Ratio (This Cabinet)," and "Cabinet Capacity (kvar)." This action will trigger a confirmation dialog box. If the settings are correct, click "OK"; otherwise, click "Cancel" to reconfigure the parameters. You may use the "Query Value" function to verify whether the settings have been successfully applied.



The screenshot shows the 'Parameter Settings Page 2' interface. It features a sidebar with navigation icons for Main, Parameter, Module, Alarm, Curve, and Wave. The main area contains a table with three columns: Parameter, Set Value, and Query Value. The parameters listed are Compensate Mode, DI-Start, Auto-Start, Power Factor, 50Hz/60Hz Change, Capacitor Switch, and Connection Mode. The Set Value column shows dropdown menus for most parameters, and the Query Value column shows the current values. A 'PgUp' button is visible at the bottom right.

| Parameter        | Set Value         | Query Value       |
|------------------|-------------------|-------------------|
| Compensate Mode  | Please Select     | Please Select     |
| DI-Start         | Disable           | Disable           |
| Auto-Start       | Disable           | Disable           |
| Power Factor     | 0.00              | 0.00              |
| 50Hz/60Hz Change | 50Hz              | 50Hz              |
| Capacitor Switch | Disable           | Disable           |
| Connection Mode  | 3-phase 4-circuit | 3-phase 4-circuit |


Figure 7.20: System Parameter Settings Interface (Page 2)

- 1) Compensation Mode Selection: Reactive Power, Reactive Power + Three-Phase Imbalance, Self-Aging. Different priority levels can be selected. Note: The Self-Aging mode should be used with caution by customers.
- 2) DI Start/Stop Enable: If the customer requires the module to be started via an external switch, select "Enable"; otherwise, select "Disable."

- 3) Auto-start Enable: If set to "Disabled," the module must be manually started by pressing the Start button after power-up; if set to "Enabled," the module will automatically start once the preset conditions are met following power-up.
- 4) Power Factor Setpoint: The actual target power factor value for the site; can be set within the range of 0 to 1.
- 5) 50Hz/60Hz Switching: Select "50Hz" or "60Hz" based on the power grid frequency.
- 6) Capacitor Switching Enable: No configuration is required; the default setting is "Disabled."
- 7) Wiring Mode: Select "3-Phase 3-Wire" or "3-Phase 4-Wire" according to the wiring requirements of the equipment.
- 8) Once parameter configuration is complete on this interface, you must click on the specific function fields located below the parameters—namely: "Compensation Mode Selection," "DI Start/Stop Enable," "Auto-start Enable," "Power Factor Setpoint," "50Hz/60Hz," "Capacitor Switching Enable," and "Wiring Mode." A confirmation dialog box will appear; if the settings are correct, click "OK"; otherwise, click "Cancel" to reconfigure. You can verify whether the settings were successfully applied by checking the "Query Value."

## 7.10 Sampling Parameters

Detailed Explanation of the Sampling Parameter Settings Interface:



| Parameter                        | Set Value     | Query Value   |
|----------------------------------|---------------|---------------|
| Input Current Sampling Position  | CT by Load    | Load          |
| Input Current Sampling Direction | Flow Out Gird | Flow Out Gird |
| Input Current CT Ratio           | 0             | 0             |
| Equipment Sampling Enable        | Disable       | Disable       |
| Equipment Sampling Position      | Cabinet       | Cabinet       |
| Equipment Sampling Direction     | Flow Out Gird | Flow Out Gird |
| Equipment CT Ratio               | 0             | 0             |

Figure 7.21: Sampling Parameter Settings Interface

- 1) Input Current Sampling Position Selection: If the field CT is connected on the incoming line side, select "Grid Side"; if the field CT is connected on the load side, select "Load Side."
- 2) Input Current Sampling Direction Selection: If the direction of the field CT points from the load side toward the grid side, select "Flowing into Grid"; otherwise, select "Flowing out of Grid."
- 3) Input Current CT Ratio: If the field CT ratio is 2000:5, set the value to "400."
- 4) Device Current Sampling Enable: This sampling function is used exclusively for whole-cabinet current sampling. If the cabinet contains more than one module, it is recommended that the

modules be connected to the cabinet's dedicated sampling CT; if connected, select "Enable"; otherwise, select "Disable."

5) Device Current Sampling Position Selection: This sampling function is used exclusively for whole-cabinet current sampling; select "Cabinet."

6) Device Current Sampling Direction Selection: If the direction of the whole-cabinet sampling CT points from the module side toward the busbar side, select "Flowing into Grid"; otherwise, select "Flowing out of Grid."

7) Device Current CT Ratio: If the whole-cabinet sampling CT ratio is 2000:5, set the value to "400."

8) Once the parameter settings on this interface are complete, you must click on the specific parameter fields located below — namely: "Input Current Sampling Position Selection," "Input Current Sampling Direction Selection," "Input Current CT Ratio," "Device Current Sampling Enable," "Device Current Sampling Position Selection," "Device Current Sampling Direction Selection," and "Device Current CT Ratio." A confirmation dialog box will appear; if the settings are correct, click "OK"; otherwise, click "Cancel" to reconfigure. You may use the "Query Value" function to verify whether the settings have been successfully applied.

## 7.11 Harmonic Parameters

The interface for the harmonic controller settings is shown in the figure below. If site requirements mandate that the module perform harmonic compensation, you may access this interface to select the specific harmonic orders to be compensated, as well as their respective compensation rates. To compensate for a particular harmonic, simply select the desired compensation rate corresponding to that specific harmonic order. For instance, if the site requires compensation for the 3rd harmonic, enter "1.00" in the field corresponding to the 3rd harmonic within the interface shown below. Finally, click "Modify"; you may then click "Query" to verify whether the settings have been successfully applied.




Figure 7.22: Harmonic Compensation Order Selection Settings Interface

## 7.12 Debugging Parameters

The debugging parameters pertain to the manufacturer's debugging interface and are not accessible to the public.

## 7.13 Module Startup and DIP Switch Settings

When two or more modules are connected in parallel, the DIP switches must be configured. The communication lines for the four modules with addresses 1 through 4 should be connected to the HMI's COM1 port (terminals 7A/8B), while the communication lines for the four modules with addresses 5 through 8 should be connected to the HMI's COM2 port (terminals 4A/9B). The module with address 1 corresponds to "Module 1" on the HMI, the module with address 2 corresponds to "Module 2," and so on.




Figure 7.23: DIP Switch Schematic

After powering on the equipment, enable the specific modules required to establish a communication link with the touchscreen via the "Module Switching Configuration" interface. Once the communication link has been successfully established, proceed to configure the

operating parameters. Provided that the parameters are set correctly and no faults are detected, the "Start Enable" indicator on the touchscreen will illuminate; the "Start" button will become active, while the "Stop" button will remain inactive. On the Module Monitoring interface, select the specific module you wish to start, then click the "Start" button to initiate the equipment startup sequence; the DC bus voltage will subsequently rise. When multiple modules are operating in parallel, the startup procedure for the remaining modules is similar.

The procedure for shutting down the system via the touchscreen—specifically when two or more modules are operating in parallel—is as follows: When the "Start" button appears inactive and the "Stop" button appears active, simply click the "Stop" button to shut down the equipment.

## 7.14 Touchscreen WiFi Network Settings

- 1) Immediately after powering on the screen, continuously press any location on the screen until the System Configuration Interface appears (as shown in Fig. 7.24); this indicates that you have successfully entered the System Configuration Interface.



Figure 7.24: System Configuration Interface

- 2) If you have already entered the main interface, please locate and click "Parameters" in the title bar on the right side. After entering the password (Password: 123), locate and click "Debug Parameters" within the interface's title bar. In the displayed Debug Parameters interface, find the "Restart" button (as shown in Figure 7.25); please click "Restart" and repeat the previous operation of continuously pressing and holding the screen.




Figure 7.25: Touchscreen Restart Interface

- 3) Once you have successfully accessed the system configuration interface, please click "System Parameter Configuration." Upon clicking, the "TPC System Settings" interface will appear (as shown in Figure 7.26).




Figure 7.26: TPC System Settings Interface

- 4) Click the "Network" option in the title bar of the "TPC System Settings" interface to display the Network Settings screen. On this screen, click the drop-down menu next to "Network Adapter," and then select "WiFi" from the options that appear. If the selection field updates to display "WiFi," the selection was successful; then, click the "Configure" button located below (as shown in Figure 7.27).




Figure 7.27: WiFi Configuration Interface 1

- 5) Clicking "Configuration" will take you to the Wi-Fi configuration interface. First, select "Enable"; then, click "SSID" to choose the Wi-Fi network you wish to connect to. Next, enter the password, and finally, click "Connect." After waiting a few seconds, the status indicator will display "Connected," signifying that the network configuration was successful (as shown in Figure 7.28). Click the "Close" button in the top-right corner to exit back to the System Configuration interface (as shown in Figure 7.29), then click "Runtime Environment" to enter the main interface.




Figure 7.28: WiFi Configuration Interface 2



Figure 7.29: Entering the Main Interface

|                                                                                    |                                                                                                              |
|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
|  | Parameter modifications must be determined by professional technical personnel; please proceed with caution. |
| Attention                                                                          |                                                                                                              |

# Chapter VIII ASVG Common Troubleshooting

Refer to Table 8.1 for common faults and solutions. Some common faults and alarm messages can be troubleshooted by the user. If the issue cannot be resolved, please contact the product engineer directly.

Faults caused by user errors, such as reversed CT connections, incorrect power line phase sequence, or parameter setting errors, can often be identified during startup and debugging by monitoring the data. If compensation performance is poor but no alarm information is displayed, please contact the product engineer.

Table 8.1: Common Faults and Solutions

| Fault and Alarm                  | Possible Reason                                                                       | Solution                                                                                                                                                                                       |
|----------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Communication Fault              | Communication issue between monitoring and ASVG Plus module.                          | Check if the communication cables are securely connected.                                                                                                                                      |
| Over temperature Fault           | High ambient temperature; blocked air ducts; fan failure                              | Check each possible reason one by one                                                                                                                                                          |
| Phase Lock Failure After Startup | Incorrect phase sequence of power lines                                               | Verify the sequence of power lines A, B, and C                                                                                                                                                 |
| AC Software Over voltage Fault   | At least one phase of the three-phase voltage is over voltage                         | Ensure that the three-phase voltage is within the operating range of the device                                                                                                                |
| AC Software Under voltage Fault  | At least one phase of the three-phase voltage is over voltage                         | Ensure that the three-phase voltage is within the operating range of the device                                                                                                                |
| Input Frequency Abnormal         | Input frequency exceeds the limit, causing ASVG Plus shutdown                         | Check if the input voltage frequency is within the device's rated range                                                                                                                        |
| DC Bus Over Voltage Fault        | High DC bus voltage causing ASVG Plus module shutdown                                 | Contact the engineer                                                                                                                                                                           |
| UP\UN\VP\VN\WP\WN Fault          | Drive fault causing ASVG Plus module shutdown                                         | Contact the engineer                                                                                                                                                                           |
| Over Current Fault               | Device output current exceeds the protection value, causing ASVG Plus module shutdown | 1) Check if the network voltage distortion rate is too high;<br>2) Check for significant voltage surges or drops in the network;<br>3) If the network voltage is normal, contact the engineer. |

## Chapter IX Contact Us

Our company has a comprehensive after-sales service system and network, dedicated to providing timely and high-quality follow-up service to both new and existing customers. If you have any questions or needs, please do not hesitate to contact us. Our technical engineers are available 24/7 to assist you.

Hertzkron | [www.hertzkron.com](http://www.hertzkron.com)