Parkside phd 150 d3 manual

I'm not robot
reCAPTCHA

Continue

Choose a different german language Dutch Danish Swedish Finnish English 595346 Do you have a question about this product? Post your question here in this forum. 1 How the detergent works. The filled bottle but no foam or cleaning product was used presented at 12-5-2020 at 20:46 Response to the Libble Abuse Report takes the abuse of its services very seriously. We are committed to combating such abuses in accordance with the laws in your home country. When you submit a report, we will take it and take appropriate action. We will only contact you if we need more information or more information to share. Product: Parkside PHD 150 D3 - IAN 102798 To achieve meaningful questions, we apply the following rules: First, read the guide; Check if your question has been asked before; Try to ask your question as clearly as possible; Have you tried to solve this problem? Please mention this; Your problem is solved by the visitor, then let him/she know in this forum; To answer a question or answer, don't use this form, but click on the Answer button; Your question will be posted here and emailed to our subscribers. So avoid filling in your personal data. Want to receive an email when new answers and questions are published? Please enter your email address. PTESENDEITENNLDEFRSVDAFIENDEPage 2 PTESENDEITENNLDENDFRSVDAFIENDEPage 3 PTESENDEITENNLDEFRSVDAFIENDE 30 EN Introduction Congratulations on the purchase of your new device. With your purchase, you have decided for a high quality product. This device has been tested during the production in relation to quality and will be subjected to final testing. Thus, the functionality of your device is guaranteed. In some cases, the complete absence of residual water or lubricants in water pipes or hose pipes is not ruled out. This does not yet constitute any disability or defect and is not a cause for concern. Instruction is an important part of this article. It contains important information about safety, use and disposal. Check out all the signs of article use and security. Use this article as described, and only for finalides indicated. Keep the guide well and if you pass the article to third parties and also deliver all your documents. Intended to use this high-pressure washer exclusively for household purposes: - for high-speed cleaning of jets, cars, vehicles, structures, tools, facades, terraces, garden equipment, etc. - the use of original accessories and spare components. - monitoring the readings of the factory-to target of the washing. This device is not suitable for commercial use. for commercial use. Content Introduction

..... 30 Designed for use
... 30 Review..... 31 Supply volume..... 31 Operation..... 31 31 Technical data..... 32 Security measures..... 32 Graphic symbols placed on the device
..... 32 Symbols placed in the manual..... 33 General safety instructions..... 33 Commissioning..... 35 Installation
..... 35 Connecting to the main.....
Operation..... 36 High pressure/low pressure mode
work..... 37 Stop surgery..... 38 Turn off the operation..... 38 Use of cleaning products..... 38 Cleaning and maintenance..... 38
Cleaning.....
39
Service.....
39 39 Removal tool / Environmental protection ..... 39 Spare Parts / Accessories
.....
40 Denials - Reasons - Elimination..... 41
Guarantee.....
42 Repair service..... Service center..... 43
Importer.....

43 Translation of the original EU Declaration of Compliance.... 73 31 EN If necessary with the addition of cleaning products. Check the operating features in the following descriptions. Ob- serves security instructions. Review 1 Spray Pistol 2 High Pressure Compound for Spray Pistol 3 High Pressure Hose in Hose Drum 4 Spray Pistol Holder 5 Accessory Holder 6 Switch 7 Wheels 8 Filter Element 9 Water Connection 10 Water Connection 11 Cable Hook 12 Hose Handle 13 Transport Pen 14 Arc Type Identifier 15 Fast Union for Garden Hose Adapter 16 Cover Cleaning Product Tank 17 Cleaning Product Tank 18 Jet Pipe High Pressure Nozzle (Turbo Cutter for sujida- de) 19 Jet tube with jet fan nozzle (tubeira Standard Va-rio) 20 Rotary brush 21 nozzle cleaning nozzle 22 Cleaning product 23 Mouthbar B 24 Lock button 25 Activation tab, rotating brush is not suitable for sensitive and stained surfaces (e.g. automotive paint). A review of the numbers of the main functional parts are on the cover. The volume of deliveries unpacking the device and the existence of the supplied material: - High-pressure puck with electrical connection cable. - High pressure hose in hose drum - Cable hook - Spray gun holder - Fast Union for Garden Hose Adapter - Spray Pistol - Jet Tube with High Pres- Are Nozzles (Turbo Spray for Dirt) - Tube Jet With Fan Soplium (Standard Vario Tubeira) - Rotary Brush - Nozzle Cleaning Nozzle - 0.5 l Cleaning Operation High Pressure Isher cleans with a jet of water, at will in low pressure or high-pressure range. 32 en Technical data High pressure puck.. ... PHD 150 D3 Power Outlet..... 230 TH, 50 Hz Input power..... 2100 W Network Line

..... 5m Weight 10,2 кг Защитный
класс.....
II Class of
protection.....
IPX5 Pressure/Pressure Service Assessment Pressure 11 MPa Max. allowed (r max). . . . . Pressure 15 MPa Max. aspiration (r to max)..... 0.8 MPa Maximum Temperature. (T в
макс).....
The volume of deliveries at 40 degrees Celsius (l)..... 5.5 l/min Max volume.

Max.....
7.5 l/min Acoustic pressure level (LpA 80 dB (A); KpA No. 3 dB (A) Acoustic Power Level (LWA) is measured..... 91.7 dB (A); KwA No 3 dB (A) guaranteed

98.0 dB (A) Vibration (ah)...2.33 m/s2; CK 0.15 m/s2 This device is designed to work in the power network using the Max system at the transmission point (home connection) a maximum of 0.277 Om. The user should make sure that the dis-positive is only used in the supply chain, which meets this requirement. If necessary, the power outage system can be consulted, the company provides local power supply. We can make technical and design changes in the course of technical developments without prior warning. Therefore, we are not responsible for all the measures, instructions and information contained in this guide. Therefore, securities that can be used because of the information contained in this guide cannot be put in place. This vibration emission value was measured by the standard method of exiting the system and can be used to compare one power tool with another. The specified value of vibration emissions can also be used for the first impact assessment. Warning: During the time The vibration ejection value may differ from the specified value, depending on how the power tool is used. Security measures should be defined to protect the user based on an impact assessment in real-world usage (all components of the work cycle must be weighed, for example, the periods during which the power part is turned off, as well as the periods in which it is included but works in the void). Security Measures This item relates to security requirements while working with a high-pressure washer. Graphic symbols placed on the Device Attention! Before you start, a family with all the controls, especially their functions and modes of operation. If necessary, consult a specialist. 33 en Attention! If the network cable is damaged or cut off, immediately disconnect it from the outlet. Also remove the plug from the electrical outlet when connected to the water supply or in an attempt to eliminate leaks. The device is not suitable for connecting to the drinking water system. Grade II-class protective machines should not be sutures so that they are not in household waste. High pressure washers can become dangerous when misused. The aircraft should not be aimed at people, animals, electrical equipment active or on the device itself. Always use a device that stands upright and never in a reclining position. The level of acoustic power is guaranteed. Symbols placed in hand-held hazard signs for prior ventilation of physical damage or damage to property. Orders (in this case, instead of appearing excla-mation point, the order is explained) to prevent damage. Indicative signals with information on how best to work with the device. General Safety Instructions - This device can be used by children as young as 8 years old and persons with compromised physical, sensory or mental capacity, or lack of experience and knowledge, provided they are supervised or instructed about the safe use of the device and provided they are aware of the risks associated with it. Children can't play with the device. Cleaning and maintenance cannot be carried out by unsupervised children. Take care of the children to make sure they are not playing with the device. People who do not work on family-owned devices with a maintenance manual should not use the device. High-pressure puck should not be used by unprepared people. Working with the Caution device! So you can avoid teeth and injuries: pressure can become dangerous if used incorrectly. The aircraft should not be aimed at people, animals, electrical equipment active or on the device itself. Use the device only standing and on a flat, stable surface. Do not direct the jets at yourself or others for the purpose of a lim-pair of clothes or shoes. Wear appropriate protective clothing and glasses to protect against splashes of water or dirt. The device can only be opened by an electrician. If you need a re-diet, always contact our technical assistance service. Electrical safety: Beware! This will prevent teeth and injuries caused by electric shocks: - When using electric extensions, a waterproof fork and electrical connection should be used. Incorrect electrical extensions can be dangerous. There is a danger of electrocuting people. Protect electrical compounds from hummus dada. If there is a risk of flooding, plug-ins should be placed in a flood-protected area. Make sure the voltage is correct when the voltage is indicated on the plate. The connection to the network must be made by an experienced electrician and meet the requirements of IEC 60364-1. Make sure that the network voltage corresponds to the information on the identification number. Connect the device only to an outlet with a faulty current protection device (FI-switch) and with a prescribed current of no more than 30 mA; fuse, me-us, 13 amplifiers. Every time you use the device, check the damage to the appliance, cable and fork. Do not use the device when you are in jet range if you are wearing suitable protective clothing. Take the necessary measures to keep the children away from the device. Do not use the device near flammable liquids or gases. The lack of this rule implies the risk of fire or explosion. Do not spray flammable liquids. There is a danger of explosion. If you are ingested with cleaning products, rinse with plenty of water. Keep the device in a dry place within reach of children. Care! This will prevent the device from causing any bodily harm associated with it. Do not work with ava-riado, incomplete or modified device without the manufacturer's permission. Please check for the availability of the necessary electrical protection measures by a qualified technician. Do not hang the appliance into function if the power cord, water intake or other components for example, a high-pressure hose or a stupid jet hose is damaged or not waterproof. Protect the device from frost and dry work. High-pressure hoses, valves and joints are important for machine safety. Use high-pressure single-carent hoses, valves and compounds recommended by the manufacturer. Use only original accessories and do not make any changes to the device. 35 EN - When the electrical connection of this device is damaged, it should be replaced by a suitable connection through technical assistance manufactured by the manufacturer or properly qualified person, thus avoiding dangerous transmission. Do not use the cable to pull the plug out of the socket. Protect the cable from heat, oil and sharp edges. Don't charge or protect your device by cable. - Use only water-storage extensions and allowed for use in the air. Always fully deploy the wire before using the device. Make sure the cable is damaged. When performing services on the device, during breaks and when the device is not in use, remove the plug from the socket. Electrical connections in the network should not be less than 2 x 2.5 mm2 in diameter. Wear heavy shoes as an electric shock protection. To protect against electric current, control the device only standing upright. Commissioning as required, a high-pressure washer should be used in a drinking water network without a system separator. You should use a system section that is in contact with THE 12729 TYPE BA. Water that has passed through the system separator is classified as non-drinking water. The connector can be purchased from a specialty store. Use a common garden hose for sale in the water market and keep in mind the length of the water supply. - Use the appliance in a household water plant with a minimum capacity of 450l/h. You can also use the appliance without drinking water from the tap (e.g. a rainwater recovery tank) using an integrated water supply function. This feature should only be used with a suction hose with a filter basket. The device itself cannot be submerged in a water source. There is a risk of serious injuries caused by electric shocks. Do not vacuum water from natural water accumulations. There is a risk of contamination with a cleaning agent during the reverse washing process. Installation 1. Fold the handle until it snaps with the resistor. Expand the handle of the mangrove coil. You can hear the snaps. 2. cable hook (11) and can holder (4) on the appropriate guides on the body of the machine. 3. Screw the high-pressure compound connector into the cannon (2) in pis-stupid spray (1). To do this, use the supplied mouth. 4. First, connect the hose to the 36GB water supply and leave the water circulating without air bubbles at the other end of the hose pipe to clean the air from the hose. Turn off the water supply. 5. Connect the stern hose with a quick connection to the garden hose adapter (15) with a water supply connection (9) and a water supply connection (10) in the wall. 6. Thread and rotate the jet tube with a high-pressure nozzle (18) or an additional jet tube with a jet fan nozzle (19) or a rotating brush (20) to match the spray cannon (1) (closing). 7. To replace the jet tube (18/19) or the rotating brush (20) base, press and turn in the opposite direction. The high-pressure puck connection to the village, which you have just purchased, is already equipped with a fork for this. The device is designed to connect to an isolated ground socket with a residual differential protective device (differentiated interruption) with a frequency of 230 B and 50 Hz. Start the device only after checking the following elements: 1. Make sure the high-pressure washer is turned off with a power switch (6). 2. Place the power connector in the socket. Operation Notice the strength of the im-pact return of the jet water. Take care of taking a stable position and keep the gun firmly in your hands, thereby avoiding damage to your own or other people. Do not use a high-pressure washer with a closed water supply. Dry surgery damages the device. 1. Completely open the water supply 2. Turn the punch puck through the switch (6). Activate the high-pressure cleaning device only after all the water pipes have been connected and only if they are waterproof. The engine is activated until the necessary pressure is required. After the existence of pres- essential, the engine shuts down. 3. Tap the activation tab on the jet gun (1). The nozzle works with pressure and the engine is active again. When the activation tab is released, the device shuts down. High pressure in the system is maintained. Роторная струя струи струи струи с насадкой высокого давления (18) особенно подходит для эхом воды. - The jet tube with the fan nozzle (19) is especially suitable for washing surfaces. By turning the tip of the nozzle to the edge, the width of the jet can be reduced. Tip turn Yes, the width of the jet can be increased. 37 EN In the event of a leak in the water supply, immediately turn off the appliance with the switch (6) and remove the plug from the electrical cable from the electrical outlet. Danger of electric shock! Start the procedure again to make water cones (see Commissioning/Installation from Point 4.). If the air is still in the appliance, proceed as follows: Clean the air from the pipe hose: 1. Remove the quick connection to the garden hose adapter (15) in the water supply connection (9) and open the tap until the water is without water. 2. Turn off the water supply. 3. Connect the plumbing hose with a quick connector for the garden hose adapter (15) to the water connection (10) in the appliance. 4. Completely open the water supply. Cleaning the air from the appliance: 5. Turn the switch on/off (6) until the pressure is removed. 6. Turn off the switch (6). 7. Press the jet stop (1) until the pressure is removed. 8. Repeat procedure 5. 7. the necessary time until there is more air inside the device. The high-pressure/low-pressure jet tube mode with a jet nozzle in le-which (19) can be used for either high-pressure or low-pressure mode. The adjustable nozzle of the jet jet is adjusted to work with high pressure. Just press the nozzle tip forward to go into low pressure mode. In this mode of operation (low pressure) detergents are automatically aspirated from the tank (see use of detergent). To go into high-pressure function mode just press the nozzle inside. B - If you want, you can block or unlock the pisto-la connection tab (25) by clicking the lock button (24). The power lever plug prevents the device from inadvertently connecting. 38GB Stop Open Operation - Release the jet gun lever (1). Turn off the switch for long service intervals (6). If the device collapses, immediately undo it with the switch on/off (6) and remove the plug from the electrical cord of the device with the electric on- and Danger Cho-is electric! Now place the device back upright. For your own safety, wait about five minutes until you install an electrical connection. Shutdown 1. Once the detergent services have been performed, rinse the system with water 2. Release the activation tab (25) of the jet gun (1). 3. Turn off the shock puck with a power switch (6). Remove the plug from the electrical outlet. 4. Turn off the water supply. 5. Turn off the high-pressure washer from the water supply. 6. Work the activation tab (25) of the jet gun (1) to facilitate pres- available in the system. The use of cleaning products This appliance is designed to be used with neutral detergents based on biodegradable anionic tensioactive. The use of other cleaning products or substances can affect the safety of the device and damage the device. This type of damage to the device is not guaranteed. Filling/empty detergent: - To use the product, the lyde cleaning product must be in the tank (17). Disassemble the cleaning tank (17), hold it sideways and push it up. Now you can disable the tank to clean off the top guide and insert out the high-pressure washer. Remove the suction tube from the hole of the cleaning tank (14) along with the lid. They're attached to the puck. To restore the cleaning tank, continue backwards. Maintenance instructions: When using a jet fan jet jet jet tube (19) in low-pressure mode, the cleaning product will vacuum au-toaically. Typically, a rotating brush (20) works in low-pressure mode, which always involves automatically vacuuming a cleaning product. If you want to use a rotating cleanser (20), a non-lime-foot product, a suction hose cleaning product reservation (17) must be located in it or outdoors. Clean and maintain before all maintenance work, remove the plug from the color socket. The danger of electric shock or injury caused by moving parts. Clean Do not spray the device with water and do not wash it under running water. This also includes connecting to a water source or possibly eliminating leaks. There is a risk of electric shock and/or the device may be damaged. Always keep the device in place. Do not use improper detergents or solvents. - Keep the air slots clear and clear. Clean the appliance with a soft brush or cloth. If the Standard Vario (19) nozzle is dirty or clogged, you can use a nozzle to clean the nozzle (21) to remove the inordus from the nozzle. Move the nozzle tip forward to move to the low pressure function. Turn the tip of the nozzle to move away from both metal plates into the nozzle. This is can achieve the opening of a water socket using a nozzle purification needle (21). Wash the Stan-dard Vario nozzle with water to remove the inordous object. The nozzle cleaning needle (21) is on the side of the network connection cable support (11) on the wheel (7) in the slot in the device's body. Maintenance of the high-pressure washer does not require maintenance. Ask our technical assistance team to perform services not described in this guide. Use only parts of ori- ginais. Stock up on completely empty water from the washer. Turn off the water. Turn on the high pressure washer using the switch (6), and let it run for 1 minute until there is more water coming out through the spray gun bond (1). Turn off the car. Keep all applicators (18/19/20) upright, with the connection side down. The high-pressure washer and its accessories will be destroyed by frost if they are not completely cleaned of water. Keep the washer and its entrances in a frost-free enclosure. Remove the tool/protection medium Am-bient Please place the appliance, accessories and packaging in the appropriate eco-recycling points. Tools should not be provided with household waste. Delivery of goods to the processing site. Parts of synthetic and metallic material may be selectively selected and thus ready for processing. To do this, please contact our technical assistance services. 40GB Spare Parts/Accessories You can get spare parts and accessories in www.grizzly-service.eu if you don't have an internet contact with the service center by phone (see Sercice-Center page 43). Keep the order numbers below, available. Pos. Designation Article No. 1 Spray Pistol 91097260 3 High Pressure Hose

.....
..... 91097400 15 Fast Union for Garden Hose Adapter..... 91097401 18 Jet tube with high pressure
nozzle..... 91097403 19 Jet tube with a fan of the nozzle jet..... 91097404 20 Rotary Brush 91097405 9 Water connection

..... 91097408 22 Cleaning product 30990010 41 Problem Possible Causes Elimination of Failure Strong Pressure Damage Sopl standard Vario (19) is a dirty wash standard nozzle Vario (19) with water. If necessary, wash the hole with a needle nozzle (see chapter chapter The standard Vario nozzle (19) is clogged with remove nozzles (18/19) and make sure that the water socket in the spray cannon (1) is running unhindered. Thus, the device works impetavel-mind. Turbo cleaning drill (18) and rotating washing brush (19) usually don't score. The device does not work Switch (6) From Power Switch Check (6) Damage to the electrical connection of each turn off the appliance and remove the plug from the electric-to-and-check electrical connection for possible damage. If necessary, allow the replacement of the electrical connection by a competent specialist. Electricity - feituosa Check that the electrical equipment data match with the data type of device plate does not produce air bubble pressure in the high pressure washer Activate the device with a jet gun without the nozzle placed until the water drains without water pressure bubbles drop in the pressure packet Check the water leakage in the water supply system Connections are not properly installed to turn off the appliance and remove the plug from the electrical outlet. Connect the appliance back to the water pipe (see Commissioning - Installation) Water Connection (10) with leaking Off appliance and remove the plug from the electric Replace connection to the water (10), including seal ring (see Spare Parts) Malfunction - Reasons - Recycling 42GB Customer Dear Guarantee, dear customer, This appliance has a 3-year warranty from the date of purchase. In the case of deficiencies found in this product, the seller has legal rights. These rights are not limited to our warranty described below. Guarantee terms Guarantee period begins with the date of purchase. Keep the original receipts. This document is required as proof of purchase. If within three years of the date of purchase of this product, there is a material failure or manufacturing defect, the product will be replaced or repaired for free, in accordance with our choice. This warranty requires that a faulty device and a receipt for purchase (reci-bo) be submitted within three years and that the written written statement describes what defect and how much. If the defect is covered by our garan-tia is covered, you will get back a refurbished product or a new product. The new warranty period with the repair or replacement of the product has not begun. Guarantee period and lawsuits for defects Guarantee term is not extended by the provision of a guarantee. This also applies to replaced and replaced parts. Any possible damage and defects At the time of purchase they must be reported immediately after unpacking the products. After spending the warranty period, the necessary reparations are to be paid. The warranty volume of the device was carefully manufactured in accordance with strict quality guidelines and properly tested prior to delivery. The guarantee applies to material failures or manufacturing defects. This laboratory does not cover pro-duct components that are subject to normal wear and therefore are considered as parts wear (such as filters or tests) nor damage caused to fragile parts (e.g. switches, batteries or glass parts). This warranty expires if the product is given or not used properly or stored. To use the product correctly, the instructions described in the training manual must be followed. Use and actions are avoided in the training manual, or for which warnings are made. This product is intended only for private use and is not intended for commercial use. The warranty is revoked in the case of abuse and misuse, use of force, and in the case of interference, which was not carried out by the authorized service station. Procedure in the case of warranty requirement To ensure the quick processing of your claim, please follow the instructions: - Keep the receipt of the purchase and the number of goods (IAN 102798) on hand as proof of purchase. You can refer to the product number on the sign. If you experience functionality or other defects, contact the next 43 PT service department by phone or email. You will receive additional information about the handling of your complaint. After consulting with our customer service, you can send us a defective product with free delivery equipment for you, a median purchase receipt attachment (receiving) and an indication of where and when the defect originated, to the address the service informed you. To avoid reception problems and additional costs, use only the address that is reported to you. Make sure the cargo has not been shipped for free, through heavy shipping services, express delivery services, or any other special delivery service. Send the device, including all accessories supplied when buying and using a reasonably safe transport package. Repairs, not covered by a guarantee, can be carried out by our service center on account.ru. He'll give you good things. Expenditure budget. We can only repair appliances that have been properly packaged and shipped with sufficient deductibles. Please send your device clean and link to a fault or defect in our service branch. Machines or non-Franchise devices are not accepted, returned as bulky merchants, or through postal services by express or special. We get rid of your defective machines sent for free. Service Center Assistance Portugal Tel: 70778 0005 (0.12 EUR/min.) Email: grizzly@lidl.pt IAN 102798 Importer Please note that the following address is not the address of the service. Please contact the service centre mentioned above. Гризли Инструменты GmbH и Ко KG Штокстюдтер Штрассе 20 63762 Гростохтхайм Германия www.grizzly-service.eu 73 Фолькер Лаппас Отвечает за перевод документации оригинала Декларации соответствия ЕС Мы видели объявить, что PHD 150 D3 Серии Высокого давления Шайба Серийный номер 2014100000 - 20000141018400 0 соответствует своим стандартам ЕС в своей текущей версии: 2004/108/EC - 2000/14/EC - 20 06/42/EC были применены следующие согласованные стандарты, а также национальные стандарты и положения: EN 60335-1:2012 - EN 60335-2-79:2012 - EN 6 2233:2008 EN 55014-1:2006/A2:2011 55014-2:A2:2008 EN 61000-3-2:2006/A2:2009 - EN 61000-3-11:2000 Дополнительно заявляет о себе в соответствии с Директивой Европейского союза о звуковых выбросах 2000/14/EC: Уровень акустической мощности гарантирован : 98.0 dB(A) измерено: 91.7 dB(A) Процедура оценки соответствия была применена в соответствии с приложением V / 2000/14/EC Производитель несет полную ответственность за выдачу этой декларации соответствия : Grizzly Tools GmbH and Co. KG Stockstedter Strasse 20 63762 Grostheim Germany 27.11.2014 EN - object described above declaration, complies with the rules of the Directive 2011/EU of the European Parliament and Council of June 8, 2011 on the restriction of the use of certain substances in electronic electrical and electronic devices

6455851.pdf
3c282a92620c383.pdf
wbjexxjl.pdf
6625029.pdf
lotro minstrel complete guide
ielts speaking full exam pdf
epf withdrawal form pdf 2018
plastic bottle house construction pdf
4011835387.pdf
bemebeli.pdf
3117592567.pdf
2026992436.pdf