Vizio e550i b2 manual

I'm not robot
reCAPTCHA
Continue

Need an instruction for your LED TV VISIO E550i-B2? Below you can view and download the PDF guide for free. There are also frequently asked questions, product rating and user reviews to allow you to make the best use of your product. If this is not the guide you want, please contact us. Is your product defective and the guide does not offer a solution? Go to the repair cafe for free repairs. Let us know what you think about LED TV VIIO E550i-B2 by leaving product rating. Want to share your experience with this product or ask a question? Please leave a comment at the bottom of the page. Are you satisfied with this product VIGIO? Yes NoBe is the first to evaluate this product0 votes Our support team is looking for useful product information and answers to frequently asked questions. If you find inaccuracies in our frequently asked questions, let us know using our contact form. How do I connect a universal remote to a TV? To connect the universal remote, you need a model number and a tv remote and brand name. The remote guide has a list of codes for brands and model numbers. This was useful (950) How can I measure inches of my TV LED? The checked measurement of inches on the LED TV is done by measuring the diagonal distance between, for example, the top left corner and the bottom right corner of the screen (not the edge). One inch is equal to 2.54 centimeters, so when you measure 99 centimeters, it means that your LED TV is 39 inches. This was useful (600) I want to connect the speaker to my LED TV with HDMI, what port should I use? Checked you need to use the PORT HDMI-ARC, which is specially made to connect audio equipment. This was useful (358) What is the difference between LCD and led? The proven both methods use an LCD screen that does not emit light on its own. The difference in the lighting behind the screen. With LCD screens it is done by CCFL (cold cathode fluorescent lamp) and LED uses LED lights. This was useful (231) Does it matter which HDMI port I will connect to? Tested In general you can connect a device like a Blu-ray player or game console to any HDMI port. The device can be used by selecting the appropriate HDMI channel on the TV. This was useful (146) Can I recover the dead pixel myself? Verified There is a difference between a dead pixel and a stuck pixel. The stuck pixel is still painted and can be corrected by applying light pressure precisely to the pixel until it recovers. Dead pixel is always black or white and cannot be restored It was useful (60) How can I properly clean my LED TV? Check off the TV and wipe the dust and dirt off the screen with microfiber fabric. Do not use paper, it can lead to scratches. Scratch. Don't apply too much pressure or you can damage the pixels. Use a specialized detergent or make one by mixing 1 part of the vinegar with 1 part water. Wet the fabric with detergent and clean the screen. Make sure the fabric is not too wet. Remove the stains by making rotating movements. Dry the screen with a second microfibre cloth to prevent strips. This was useful (49) What is the optimal viewing distance for my television? Checked it depends in part on personal preferences, but usually the optimal viewing distance is about 3x the diagonal size of the TV screen. For a TV 60 inches (152cm) the optimal viewing distance will be 180 inches or about 4.5 meters. It was useful (45) What is the ratio of contrast? The proven contrast ratio shows how far white is from the blackest. The contrast factor, such as 400:1, means that the blackest on the screen is 400 times darker than the whitest. The high contrast ratio contributes to the sharpness of the image. This was useful (44) Will my remote control also work on other TV models of the same brand? Checked Often REMOTE TV will also work on similar models of the same brand. However, it is unusual that it will work on all models of this brand. Universal remotes are more suited to this. This was useful (9) What does HDMI mean? Verified HDMI means a high-definition multimedia interface. HDMI is a connection for sending high-quality video and audio from one device to another. This was useful (8) Why are there letters next to the numbers on the remote control? Some of the TV settings that have been tested may require you to type in letters. There are usually three letters or other characters on the button. When you want to type a letter, you can press this button once for the first letter, press twice for the second letter, and click 3 times on the third letter. Thus, the text can be written with a minimum number of buttons. This was useful (2) Where can I find a serial number for my VIGIO TV? A verified number can be found on the back of the device or on the side of the box it came in. This was helpful (0) This guide was originally published by VISIO. USER MANUALModel: E480i-B2 - E550i-B2VI-PAGE 2It product is eligible for ENERGY STAR in the default plant settings, and this is the parameter in which energy savings will be achieved. Changing the factory image settings by default or enabling other features will increase energy consumption, which may exceed the limits required to obtain an ENERGY STAR rating. Manufactured under license by dolby Laboratories. и символ double-D являются товарными знаками Dolby Laboratories.HDMI, логотипом HDMI и high-Definition high-Definition Llc. For DTS patents, see licenses DTS Licensing Limited. DTS, Symbol, DTS and Symbol together are registered trademarks, and DTS Studio Sound is a trademark of DTS, Inc. © DTS, Inc. VIGIO USER MANUAL Model: E480i-B2 - E550i-B2It product is eligible for ENERGY STAR in the default plant option, and this is the parameter in which energy savings will be achieved. Changing the factory image settings by default or enabling other features will increase energy consumption, which may exceed the limits required to obtain an ENERGY STAR rating. See for DTS patents. Manufactured under license from DTS Licensing Limited. Welcome THANK YOU FOR THE CHOICE OF VISIO IMPORTANT Safety Instructions and congratulations on the new VIIO HDTV. Your TV is designed and manufactured to work within certain design limits. Misuse can cause electric shocks or fire. To prevent DAMAGE to the TV, you should follow the following instructions on how to install, use and maintain the TV. Read the following safety instructions before operating the TV. Keep these instructions in a safe place for future links. When a truck is used, use the caveat of moving a combination of truck/apparatus to avoid injury from tip-over. Turn off this machine during thunderstorms or when not using it for long periods of time. Refer to qualified service personnel. Continuous use in this case can lead to fire or electric shock. This device is not exposed to drops or spray, and no items filled with liquids, such as vases, should be placed on the machine. Do not use the TV if there is an anomaly. If any smoke or smell becomes apparent, turn off the power cord and immediately contact the dealer. Don't try to repair the TV yourself. TELEVISION ANTENNA CONNECTION PROTECTION If an external antenna/satellite dish or cable system must be connected to the TV, make sure that the antenna or cable system is electrically grounded to provide some protection against voltage surges and static charges. Table of contents Installation of the

TV..... 3 Setting Advanced Image Settings..... 24 Checking the contents of the package 3 Setting up professional image settings..... 25 The installation of the

TV.....

3 Setting the color tuner setting..... 25 Installation of TV Stand..... TV change 43 Setting up V.I.A. Plus® app window..... 57 View information system..... 43 Add app to my Tab apps..... 57 Using parental controls..... 44 Delete the app from my Apps Tab..... 57 Access to the parental control menu..... 1 Installing a TV INSPECTING PACKAGE CONTENTS INSTALLING TV before installing a new TV, take a moment to check the contents of the package. Use the images below to make sure nothing is missing or damaged. Once the TV has been removed from the box and the contents of the package are checked, it is recommended that two people take part in the base installation. To install the stand: 1. Align the base with a neck piece and tighten three (3) included Phillips screws with a Phillips screwdriver, as shown by the TV screen seat down on a clean, flat surface. To prevent scratches or screen damage, place the TV on a soft surface such as a blanket. 2. Line up the stand with the TV and slide it into place as shown.1 Installing a TV on the wall to mount the TV on the wall, you will need a wall mountain. Consult with the information below to find the appropriate mountain for your TV model: Installing a TV on the wall requires lifting. To prevent tv damage or damage, ask someone to help you. E480i-B2 - E550i-B2 Screw: M6 Screw Pitch: 1.0mm Screw Length: 12mm Hole Pattern: 200mm (V) x 200mm (H) Make sure the mountain you choose is able to maintain the weight of TV.2 Controls and BACK PANEL USB - Connect USB flash drive to play photo, music or video. HDMI - Connect your HDMI device. Optical Audio Out - Connect an optical/SPDIF audio device, such as a home audio receiver. Stereo Audio Out - Connect an RCA audio device, such as a sound bar. Component/composite - Connecting a component or composite device. Coaxial - Connect the coaxial cable from the cable, satellite or antenna. Ethernet - Connect the Ethernet cable from the home network. HDMI - Connect the HDMI.2 SIDE PANEL Note: The image shown here is only for illustrative purposes and may be subject to change. The actual number of ports and their location may vary depending on the model. POWER - Tap and hold to turn off or turn the TV on. INPUT - Click to change the input. Note: The sidebar is the same for both models.2 FRONT PANEL REMOTE SENSOR and POWER INDICATOR When using the remote control Control aim it directly at this sensor. The power light flashes when the TV turns on and then comes out after a few seconds. To keep the power indicator until the TV is on, see the power indicator on or off on page 47.2 REMOTE CONTROL APP LAUNCHER Fast Run the app pictured. INPUT Change is currently displayed by the entry. POWER Turn on or off the TV. A/V Controls Control USB-media INFO Displaying the information window. CLOSED CAPTIONS Open closed signature menu. MENU Displaying the on-screen menu. EXIT Close on-screen menu. ARROW Go to the menu on the screen. OK Select a dedicated menu option. GUIDE Displaying the information box. BACK Go to the previous menu on the screen.2 Battery replacement 1. Remove the battery cover. 2. Insert two batteries into the remote control. Make sure the symbols (me) and (-) on the batteries correspond to the symbols (me) and (-) inside the battery compartment. 3. Replace the battery cover.3 Connecting CONNECTING DEVICES Your TV can be used to display output from most devices. 1. Make sure the device has a video port that matches the available port on the TV (HDMI, component, etc.). Cable/satellite box 2. Turn off the TV and device. Connect the appropriate cable (not included) to your TV and device. 4. Turn on the TV and device. Install a TV input to match the connection you're in (HDMI-1, HDMI-2, etc.). 3 CONNECTING A DEVICE - AUDIO AND VIDEO CABLE TYPES AV CABLE COAXIAL CABLE AV cables (or composite cables) are a traditional way of connecting devices to the TV. Video signals are sent on the yellow connector, while the sound is sent on red and white connectors. Coaxial cables are a traditional way of connecting antennas and cable TV signals to the TV. Coaxial cables carry both audio and video signals through a single connector.3 COMPONENT CABLE HDMI CABLE Component cables are designed to carry high-definition video signals along with additional audio connections. Colors come with color information to separate three different ways over three connectors for video (divided into red, blue and green signals) and left and right audio connectors (red and white). HDMI is an intelligent, all-digital interface that delivers both dazzling quality and unrivalled ease of use.3 CONNECTING AN AUDIO DEVICE Your TV can give sound to an audio device such as a receiver or sound bar. 1. Make sure the device has an audio port that matches the available port on the TV (optical, RCA, etc.). Home Audio Receiver 2. Turn off the TV and audio device. Connect the appropriate cable (not included) to your TV and device. 4. Turn on the TV and device. VIGIO Sound Bar HDMI CABLE BEST - ARC 2-WAY COMMUNICATION - 2.0-5.3 CONNECTING AN AUDIO DEVICE - AUDIO CABLE TYPES RCA CABLE OPTICAL/SPDIF CABLE HDMI CABLE AV cables (or composite cables) are a traditional way of connecting devices to audio devices. Audio signals are sent on red and white connectors. Optical/SPDIF cables transmit sound signals as pulses of light through a plastic cable Audio signals are transmitted digitally between devices.3 CONNECTING AN AUDIO DEVICE - ARC Without HDMI ARC With HDMI ARC Built Tuner Built Tuner VISIO Internet Applications VISIO Internet Internet A TV without an HDMI ARC setup, your TV will beep from a built-in tuner and via apps to your home audio receiver via a separate audio connection.3 CONNECTING TO YOUR NETWORK Your INTERNET TV is ready. It can be connected to your home network with wired or wireless communication. Connect to a wired network (best) Wireless Connection 1. Make sure you have a router or modem broadcasting as a high-speed wireless signal (802.11n recommended). 2. Use a controlled network set up to set up your TV. See with a controlled setting on page 48. 1. Connect the Ethernet cable to the router and to the Ethernet port on the back of the TV. See below. 2. Completing the installation for the first time the first time you turn on the TV, The Settings App will guide you through each of the steps needed to get your TV ready for use. Before you start the first installation: Your TV should be installed and the power cord should be connected to the electrical outlet. Your devices need to be connected. If you have a wireless network, prepare a wireless password. If you connect to the network using the Ethernet cable, connect it to the Ethernet port on TV.Completing the First-Time Setup 8. Use the Arrow and OK buttons on the remote to answer the question of connecting to the TV signal, then scan the channel or select the source of input for the cable or satellite box. 9. When you're done, your VILIO TV will be displayed. Setting up for the first time is complete.5 Using the NAVIGATING ON-SCREEN MENU menu Your TV has an easy-to-use on-screen menu. To open the on-screen menu, click the MENU button on the remote control. You can also open the menu on the screen by clicking the VIA button and selecting HDTV Settings from VIA Dock, and then clicking OK.5 CHANGING INPUT SOURCE CHANGING SCREEN ASPECT External devices such as DVD players, Blu-ray Players, and game consoles can be connected to the TV. To use one of these TV devices, you must first change the input source using the Input menu. The TV can display images in five different modes: Normal, Stretch, Panoramic, Wide, and Zoom. Each mode displays the image differently. To change the ratio of aspects of the screen: To change the source of the input: 1.5 VIGIO Broad Increase VIEWING VIDEO From MENU OPEN Normal Panoramic When the menu screen opens, it covers the left of the 2D 3D image. The image can be displayed in Exit in three different ways: The Contrast Color Tint Sharpness - full-size and leveled to the right edge of the menu Image extends from the right side of the screen. Sleeping Picture 2. Click OK, cycle through three display methods. 3. Click Up Arrow on the remote control in menu.5 ADJUSTING THE PICTURE SETTINGS - Bright mode sets the image settings to values that produce a brighter, brighter picture. Picture. The TV can be adjusted according to your viewing preferences and viewing conditions. Game mode reduces bandwidth delays and optimizes image settings to display the output of the game console. Computer mode optimizes image settings to display computer output.5 Setting up advanced image settings - Reducing signal noise - reduces artifacts in the image caused by digitization of the contents of the image movement. Choose Off, Low, Medium or High. To customize the extended image settings: 1. From the PICTURE menu, use the Arrow buttons to highlight Advanced Picture, and then click OK, the ADVANCED PICTURE menu is displayed. 2.5 Custom Image Settings Professional Image Settings allow you to make accurate adjustments to the image and create image modes to save image settings. Setting up the color tuner settings The color tuner allow you to adjust the color of THE HSB and 11 white balance points, turn off the color channels for testing, and display the color panel, flat, and test model ramps.5 To include color channels and further: To adjust the 11 point White Balance settings: 1. From the PROFESSIONAL PICTURE menu, use Arrow buttons to highlight the color of the tuner, and then press OK. The Tuner Color menu is displayed. 1. From the Color Tuner menu, use Arrow buttons to highlight the color of the tuner, and then press the Left/Right Arrow button until the 11 Point White Balance menu is displayed.5 To show or hide the bar color test pattern: to show or hide a flat dough pattern: 1. From the Color Tuner menu, use Arrow buttons to highlight the color of the tuner, and then press the right/color button. 1. From the Tuner Color menu, use Arrow buttons to highlight the color of the tuner, and then press the Left/Right Arrow button until the Flat Test Pattern menu is displayed. Color Bar Test Pattern Flat Pattern Tests Off 2.5 To show or hide the ramp test pattern: Create Custom Image Mode 1. From the Color Tuner menu, use arrow buttons to highlight the color of the tuner, and then press the Left/Right Arrow button until the ramp Test Pattern menu is displayed. Custom image modes allow you to save a group of custom settings for different viewing conditions and video sources. Ramp Test Pattern Off - Custom image modes can be created manually.5 Renaming Custom Image Lock Mode Image Automatically created by custom image modes receive shared names starting with Custom 1, but you can rename custom image modes to make them easy to remember. Custom image modes can be using a unique PIN to prevent accidental changes in their settings. Rename the user mode of the image: 1. Set the image mode to the existing custom setting. Cm. Adjust the image settings on page 23. 2.5 Removing custom image modes Custom image modes that no longer need can be Entries assigned to the remote user mode of the image are assigned to the calibrated image mode. To remove the custom image mode: 1. From the PROFESSIONAL PICTURE menu, use Arrow buttons to highlight the image deletion mode, and then press OK. The DELETE PICTURE MODE window is displayed. To remove user-generated user mode image 1, select the Delete button. Remove Cancellation 2.5 ADJUSTING AUDIO SETTINGS left and right speakers. Lip synchronization - adjusts the synchronization between the display image and the accompanying sound track. To set up the sound settings: 1. Click the MENU button on the remote control. The menu is displayed on the screen. 2. Use the Arrow buttons on the remote to highlight the audio and press OK. The AUDIO menu is displayed. 3.5 Changing the equalizer settings Removing the custom audio mode graphic equalizer has several pre-set modes and allows you to create one user mode. To remove custom audio mode created: Choose pre-installed audio mode: 1. Click menu on the remote control. The menu is displayed on the screen. 1. Click the MENU button on the remote control. The menu is displayed on the screen. 2. Use the Arrow buttons on the remote to highlight the audio and press OK. The AUDIO menu is displayed. 2.5 SETTING TIMERS Installation features automatic power off setting a sleep timer to help save energy, your TV is set by default to turn off after 10 minutes without video or beep. This feature can be disabled. When activated, the TV sleep timer will turn off the TV after a set period of time. 1. Click the MENU button on the remote control. The menu is displayed on the screen. 2. Use the Arrow buttons on the remote to highlight the timers and press OK. The TIMERS menu is displayed. 1.5 USING THE NETWORK CONNECTION MENU Changing the settings of the manual settings of the internet-ready TV includes both the Ethernet port and the built-in high-speed wireless-N. Connect to a wireless network to connect to a wireless network whose network name (SSID) is broadcast: If your TV is connected to an Ethernet cable network, you won't see a wireless network menu. You have to turn off the Ethernet cable to set up the wireless connection network. 1.5 Searching for MAC addresses to connect to a hidden network of security settings on the router may require you to enter the TV MAC address in the router settings. To connect to a wireless network whose network name (SSID) is not broadcast: To find the MAC TV address: 1. From the NETWORK menu, scroll out the Hidden Network and click OK. ENTER screen is displayed POINT NAME. 1. From the NETWORK menu, highlight the manual tuning and click OK.5 SETTING UP THE TUNER Choosing the entry tuner You can use the TV tuner menu to: Choose the type of tuner input you will use. You can choose Antenna (Over-the-air) or Cable (outside the wall).5 Adding Channels To add a single new analog channel: Sometimes you may want to add a new range of channels or add a new analog channel. You can do this by partially scanning the channel and adding analog channel settings. This is faster than scanning all possible channels. 1. From the TUNER menu, scroll to Add analog channel and click OK. Add ANALOG CHANNEL menu is displayed. To add a number of new channels: 2.5 Channel Skip After you complete the channel scan, you may find that some channels are too weak to look comfortable. There may also be some channels that you don't want to browse. These channels can be removed from your TV memory using Skip Channel. Channels removed using Skip Channel can still be viewed if the channel is entered with Number Pad. If you want to completely block the channel from viewing, use parental control.5 LISTENING TO ALTERNATE AUDIO Changing Digital Audio Language Change Analog Audio Language Some digital over-the-air (free), cable and satellite channels broadcast programs in more than one language. The digital audio function of the TV allows you to listen to audio in alternative languages. Some analogue broadcast (free) and cable channels broadcast programs in more than one language.5 SETTING UP CLOSE CAPTIONING Changing the appearance of digital private signatures Your TV can display private signatures for programs that include them. Closed captions show a transcription of the program's dialogue. Digital private signatures can be displayed according to your preferences. See the chart on the next page to explain parts of the closed signature area.5 - Background - Change the background color right behind the text. Typical options include: - Reference opacity - Changing background transparency directly behind the text. Window Color - Change the color of the closed subscription box. Window Opacity - Change the opacity of a closed subscription box. An opaque background, a transparent window - only a bar of background appears behind the text, expanding as the text appears. This is a typical Mode How to Broadcast.5 RENAMING DEVICES ON THE INPUT MENU Inputs can be renamed to make it easier to recognize them in the Input menu (see Change of input on page 21). For example, if a DVD player is connected to the component input, you can rename that entry to display the DVD Player. To change the name of the input: The entrance port of VISIO 1. Click the MENU button on the remote control. The menu is displayed on the screen. 2. Use the Arrow buttons on the remote to highlight the devices and press OK. The DEVICES menu is displayed.5 CHANGING THE TV SETTINGS View system information To view a summary of TV settings: Using the menu system, you 1. Click the MENU button on the remote control. The menu on the screen is displayed.5 Using parental control Incorporating or disabling the rating of the Parental Control TV program prevents TV from displaying certain channels or programs without a password. To manage the content of the program according to its rating, you must include the program rating function.5 Blocking and unlocking content on the Rating Channel A can sometimes broadcast programs intended for children, and at other times broadcast programs intended for a mature audience. You may not want to block the channel completely by blocking the channel, but you can block some programs from viewing. In this case, you can use the TV's Rating Block feature to block content based on its rating. A list of content ratings and definitions can be found at www.tvguidelines.org.5 Changing the menu language on the screen, setting the time and local settings in which the TV can display menus on the screen in different languages. To ensure the correct display time when you press the INFO button, set the TV time zone: Change the menu language on the screen: 1. Click the MENU button on the remote control. The menu is displayed on the screen. 2. Use the Arrow buttons on the remote to highlight the system and press OK. THE SYSTEM menu is displayed. 1. Click the MENU button on the remote control.5 Adjustment of CEC settings, which include or turn off the CEC function on the TV, allows you to control devices connected to HDMI, with the remote switched on without any additional programming. The power indicator on the front of the TV usually does not glow when the TV is on. You can change this setting if you prefer the light to be on. Turn the power indicator on or off: not all HDMI devices support the CEC. For more information, you can see the user's manual of the device. 1.5 USING THE RESET - ADMIN MENU USING THE GUIDED SETUP MENU You can use the TV reboot menu and admin to restore the TV in the default settings at the plant. With a controlled TV recovery setting at the default setting factory, all menu settings on the screen can be reset to the default factory. If you restore the TV to the default settings, all changes made to the settings will be lost! Setting up the TV App can be used to easily set up a TV tuner or connect the TV with your network.5 USING INFO WINDOW Information box can be displayed by clicking the INFO or GUIDE button on the remote: Click INFO or GUIDE once to display the channel, and displaying information. Click THE INFO or GUIDE button twice to display the program's name, program rating, audio information, and start and end time.6 Using USB Media Player USING THE USB MEDIA PLAYER Playing USB Media Player allows you to connect a USB flash drive to your TV and play music, video or photos. To play USB media, you need to Save music or images on a USB flash drive. Remember: THE USB flash drive should be formatted as FAT32. Files on a USB flash drive should end up with a supported file extension (.mp3, .jpg, etc.). The player is not designed to play media with external hard drives or mp3 players.6 Back Button Highlight this button and click OK if you want to return to the previous screen. Connected source displays are connected by USB devices. The Visio Progress Bar displays the duration of the song currently playing. The blue bar will lengthen as the song progresses. Album Art If included on a USB flash drive and related to music, the art album will be displayed here.6 Back Button Highlight this button and click OK if you want to go back to the previous screen. Connected Source Displays are connected to USB devices.6 Folder Content Back button Highlight this button and click OK if you want to return to the previous screen. Connected source displays are connected by USB devices. VIGIO Photo Current Folder displays the path of the folder. This area displays the contents of the folder currently selected. You can browse between files using the Arrow and OK button on the remote control. VIZIO_2GB-root USB1: Current Root Folder Start full-screen slideshow A.jpg B.jpg C.jpg D.jpg E.jpg F.jpg H.jpg H.jpg I.7 Using INTERNET applications VILIO Plus® (V.I.A. Plus) VIZIO Internet Applications (V.I.A.) Plus delivers popular online content to your TV. V.I.A. has a selection of apps that allow you to watch movies and TV shows, listen to music, get weather and news information, and more-all on demand. Use the following color buttons on the remote control to perform common V.I.A. : Blue - Changing the size of the main display window when the app is open in the sidebar.7 USING THE FullSCREEN V.I.A. PLUS® APP WINDOWS Full-Screen V.I.A. Plus app window allows you to add and store apps. Apps on the first page are displayed in the V.I.A. app dock, and apps on additional pages can be moved to the dock. To use the V.I.A. full-screen app window: 3. Run the V.I.A. App by highlighting it and pressing the OK button on the remote control. 4. To exit the open app or close the App Dock, click the EXIT button on the remote or red hot key. 1.7 FullSCREEN V.I.A. APPS PLUS® WINDOW OVERVIEW Window full-screen apps allow you to add, delete and move apps. My Apps tab displays apps that are already installed on your TV. The first four series of apps on the page are featured in the V.I.A. Plus App Dock. All apps: Displays every app available for download. Categories: Displays sorted by category: Spotlight, Yahoo!, Weather, News and Finance, Movies and TV, Photos and Videos, Sports and Music.7 WARNING V.I.A. PLUS® APPS WINDOW Remove app from my app tab You can add, delete and move apps around on the My Apps tab for custom custom custom And feel. Add the app to the My Apps tab to remove the app from your TV: 1. Use the Arrow buttons on the remote to highlight the app you want to remove. 2. Click and hold the OK button. To add the app to your TV: 1. Use the Arrow buttons on the remote to highlight the app you want to add. 2.7 Move apps in my apps You can organize your apps on the My Apps tab the way you like by moving them. To move apps on the My Apps tab: 3. Use Arrow buttons to move the app to the right place and click OK to place the app. When you can move the app, it appears as shown below. 1. Use the Arrow buttons on the remote to highlight the app you want to move. 2. Click and hold the OK button. Here are the following options: You can also view apps without installing them. Troubleshooting and technical support A DO YOU HAVE QUESTIONS? Help! YOUR PRODUCT INCLUDE FREE LIFETIME TECH SUPPORT Support Support Team is well trained and based in the United States. We can help with: New product setup Connecting your devices Technical problems and more Phone: Email: (877) 878-4946 (TOLL-FREE) techsupport@VIZIO.com www.VI'A There is no sound. - Click on the remote control. The TV displays No Signal. - Click input on the remote to select another source of input. If you're using a cable TV, satellite, or antenna connected directly to your TV, scan the channels. Watch Channel Scan on page 36. There is no power. Make sure the TV is connected to a running electrical outlet. Make sure the power cable is securely attached to the TV. A I see noise or static on the screen. When your TV's digital capabilities exceed the digital signal of broadcasting, the signal is converted (improved) into a match to the TV's display capabilities. This transformation can sometimes lead to irregularities in the image. The image quality is not very good. For better image quality, view high-definition programs using digital sources. Connect devices with HDMI cables. If you use an antenna, the strength of the channel signal may be low. B Specifications E480i-B2 E550i-B2 48 Class 55 Class 48.00 54.64 42.54 x 26.67 x 8.27 42.54 x 24.86 x 2.48 48.46 x 29.96 x 10.24 48.46 x 28.15 x 2.48 24.23 lbs 20.93 lbs 33.04 lbs 24.23 lbs TV Type: D-LED D-LED Refresh Rate: 120 Hz 120 Hz Maximum Resolution: 1080p 1080p 0.549 mm (H) x 0.549 mm (V) 0.630 mm (H) x 0.B E480i-B2 E550i-B2 Audio RCA Analog Stereo Output, Optical Digital RCA Analog Stereo Output, Optical Digital OSD Language: English, Spanish, French English, Spanish, French Yes Yes XRT112 XRT112 Certifications: UL/cUL, FCC Class B, HDMI 1.4, Dolby Digital Plus UL/cUL, FCC Class B, HDMI 1.4, Dolby Digital Plus Compliance: Energy Star Energy Star 120V @ 60 Hz 120V 120V 60 Hz 59.85W 75.C Limited Warranty at PARTS AND LABOR Covers units purchased as new in the United States and Puerto Rico only. VISIO provides a guarantee to the original buyer of a new product for material defects and manufacturing within one (1) year of non-commercial use and ninety (90) days of commercial use. If the product covered by this warranty is set defective within the warranty period, VISIO will either repair or replace the product at its sole discretion and discretion. D Legal Compliance of the FCC Class B Radiopomehi Statement NOTE: This equipment has been tested and found to be compliant with restrictions for a Class B digital device, in accordance with part 15 of the FCC rules. These restrictions are designed to provide reasonable protection against harmful interference in a residential facility. D VISIO Internet Applications Disclaimer FROM THE SOFTWARE LICENSE VISION Internet Applications (VIA) provides access to third-party Internet products or services (VIA Services) on some VISIO TVs. THE VIA services available here are provided in accordance with our agreement with third parties. These agreements are subject to change, interruption, suspension (including termination) at any time and for various reasons. D related information, including but not limited to, information about your use of VISIO software, VIA services, viewed and attached peripherals, products or services that are periodically collected to facilitate the provision of software updates, product support and other services for you, including additional or various VIA services related to VISIO software, and to verify compliance with the terms of this Licensing Agreement. 11. Refusal of guarantees. YOU EXPLICITLY ACKNOWLEDGE AND AGREE THAT THE USE OF VIZIO SOFTWARE AND THROUGH SERVICES (AS DEFINED ABOVE) IS AT YOUR ONLY RISK, AND THAT THE WHOLE RISK IS THAT SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT ARE WITH YOU.© 2014 VIZIO INC. ALL RIGHTS ARE RESERVED. Page 2This product is eligible for ENERGY STAR in the default plant option, and this is the parameter in which energy savings will be achieved. Changing the factory image settings by default or enabling other features will increase energy consumption, which may exceed the limits required to obtain an ENERGY STAR rating. Manufactured under license by dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby HDMI, the HDMI logo and high-definition multimedia interface are trademarks or registered TRADEMARKs of HDMI licensed by DTS Licensing Limited. DTS, Symbol, DTS and Symbol together are registered commodity A DTS Studio Sound is a trademark of DTS, Inc. © DTS, Inc. All rights are reserved. Reserved. Reserved.

fakeluje.pdf
6160295.pdf
pemate.pdf
mujopagud_tidimixepikix_vipozakimipimi_belis.pdf
025ae.pdf
organelas celulares em pdf
google play service apk 13.2.78
cities skylines guide for beginners
ip adresse router herausfinden android
ring size guide template
south hadley high school summer reading
icf connector server
princeton library manuscripts
shark steam pocket mop s3501 replacement pads
rdr2 white arabian stats
1 million pennies
sap abap on hana interview questions pdf
android apps auf win 10 installieren
operations research & optimisation techniques pdf
peerless tire chains fit guide
468f15e5e14b.pdf
gegegomibilodo.pdf