








# 1








# 2







# 3







# 4








5





6




! 180°






# 7






# 8






9






# 10







# 11






# 12






# 13






# 14








# 15






# 16






# 17






# 18






# 19






# 20





# 21





# 22


## Alkaline batteries option



AA

$1.5V \times 4 = 6V$

! VIN




## Ni-Mh rechargeable option



AA


$1.2V \times 4 = 4.8V$








# 23






# 24





# 25





# 26

[builders.ottodiy.com](http://builders.ottodiy.com)

