

FOB Programming Procedure

Ferrari 355, 360, 456, 550, 575

(Comments added)

Before getting started, gather your new master fob, two slave fobs and the vehicle's current PIN code and enter car.



You must have the vehicle's **current PIN code**. If you don't have it, STOP. You will not be able to program fobs to the car.

1. Insert key in ignition and wait approximately 20 seconds for the alarm LED on the dash to start slowly flashing.
2. Enter the first PIN digit by switching the key from **ON** to **OFF** the number of times corresponding to the PIN digit. If a digit is "0", turn the key **ON** and **OFF 10 times**.

Example: PIN digit =3:

key **ON** / key **OFF**

key **ON** / key **OFF**

key **ON** / key **OFF**



Do not leave the key in either position for more than **2 seconds**.

3. After entering the 1st digit, leave the key **OFF** for **5 seconds**.
4. Repeat steps 2 and 3 for the 2nd, 3rd and 4th PIN digits.
5. After entering the 4th digit, wait **5 seconds** and turn the key back **ON**.
6. If the code was accepted, the LED will turn on for approximately 5 seconds and then go off.

IMPORTANT

If the LED fails to turn on and go off, one of the following has occurred:



- The wrong PIN was entered.
- A mistake was made entering the PIN.
- The proper timing was not followed.

Check that the PIN is correct and start over.

7. Turn the key **OFF** then back **ON**.
8. The LED will turn on for approximately 5 seconds then go back off.
9. As soon as the LED goes OFF, turn the KEY **OFF** then back **ON**.
10. Repeat steps 8 and 9, **10 times**.
11. When you turn the key on for the 10th time, the LED will start flashing.



The flashing LED indicates the immobilizer has entered learning mode.

12. Now press and hold the button on the new master remote until the alarm LED flashes rapidly, then release the button.
13. Repeat step 12 for the two slaves. If all remotes have been accepted, the LED will turn on steady.



Programming is complete!

14. Turn the ignition off and test the remotes.

FOB Programming Procedure

Ferrari 355, 360, 456, 550, 575

Before getting started, gather your new master fob, two slave fobs and the vehicle's current PIN code and enter car.

1. Insert key in ignition and wait approximately 20 seconds for the alarm LED on the dash to start slowly flashing.
2. Enter the first PIN digit by switching the key from **ON** to **OFF** the number of times corresponding to the PIN digit . If a digit is "0", turn the key **ON** and **OFF 10 times**.

Example: PIN digit =3:

key **ON** / key **OFF**
key **ON** / key **OFF**
key **ON** / key **OFF**

3. After entering the 1st digit, leave the key **OFF** for **5 seconds**.
4. Repeat steps 2 and 3 for the 2nd, 3rd and 4th PIN digits.
5. After entering the 4th digit, wait **5 seconds** and turn the key back **ON**.
6. If the code was accepted, the LED will turn on for approximately 5 seconds and then go off.
7. Turn the key **OFF** then back **ON**.
8. The LED will turn on for approximately 5 seconds then go back off.
9. As soon as the LED goes OFF, turn the KEY **OFF** then back **ON**.
10. Repeat steps 8 and 9, **10 times**.
11. When you turn the key on for the 10th time, the LED will start flashing.
12. Now press and hold the button on the new master remote until the alarm LED flashes rapidly, then release the button.
13. Repeat step 12 for the two slaves. If all remotes have been accepted, the LED will turn on steady.
14. Turn the ignition off and test the remotes.