

Continue



## Digital mp4 player zy model t1 user manual

### Digital mp4 player/zy manual.

Dear user, Thanks for choosing our Digital MP4 Player! To ensure a smooth experience, please read this manual carefully before using your device and keep it in a safe place. Our product features: \* 65K color OLED display \* Support for various music formats (MP1, MP2, MP3, WMA) \* Original AMV display \* Disk separation function with adjustable coded part \* Full frequency FM radio with over 40 stations Controls: \* Power on/off button \* Earphone hole and USB Port \* Play/Stop button \* MENU/MODE buttons (enter main menu or submenu) Key functions: 1. Power: On/off, play/pause/stop 2. MENU/MODE: Enter main menu or submenu 3. PLAY: Switch on/off, play/pause/stop 4. NEXT: Short press next, longer press quick forward 5. LAST: Short press last, longer press quick backward Repeat playing: \* File format and bit rate display \* Volume control \* File directory ID3 tag icon Song/singer name Battery icon Song # Battery level (9-level monitoring system) Browsing music files or menus: \* Press Last to forward and Next to backward \* Fast forward or fast backward when playing music Entering different modes: \* Long press MENU button to enter different modes (Music, Voice, etc.) To confirm menu button and display lyrics, this player supports .LRC files from Freedata Technology co., Ltd's website. The device records voice with a battery level check to prevent low power issues. It can store up to 99 recorded files per directory. ###Recording Mode Steps 1. Enter the main menu. 2. Press "Next" to select record mode. 3. Choose between REC Type options: Fine REC, Long REC, and Fine VOR. 4. Confirm the selected recording type. 5. Select the desired recording type. 6. Confirm the recording type selection. ###Converting ACT Files The player can convert ACT format files to WAV through accessory installation tools: 1. Run the "Sound Converter" program. 2. Choose the ACT files for conversion. 3. Save the converted file in WAV format. ###Saving Stations and Play Methods - To save a station, enter FM submenu, select Save, choose the station, and confirm saving it. - Delete stations by selecting the option to delete all saved stations. - Set play method: auto-play or manual play with adjustable time intervals (in seconds). ###System Setting 1. Enter main menu. 2. Select System setting icon. 3. Confirm entering System Setting submenu. 4. Adjust system parameters as needed, which may vary based on firmware upgrades. ###Power Off and Firmware Upgrade - Set power off timer: after a fixed period (in seconds) with no key operation in Stop mode, the player turns off automatically to save power. - Firmware upgrade promotes performance optimization but requires correct operation to avoid issues. Files and FM stations can be removed at corresponding modes in Music Mode, Voice Mode, or FM Mode. To delete a file or station: \* In Stop Interface mode, select "Local folder Delete" to remove a file. \* Or, go to the Play Submenu, navigate to Play Mode, and choose the files you want to play. The player will play the selected files according to the chosen mode. You can also repeat single music files or play them in normal sequence. To adjust tempo rate: \* Press Menu to enter the Play Submenu. \* Select "Tempo Rate" and use the Next button to increase or decrease the tempo. You can also replay a specific segment by selecting Follow Read Mode. This feature does not exist in Voice Mode, however. A private space function is recommended for users concerned about information disclosure and data privacy. The format tool allows you to partition and encrypt disks. To do so: \* Choose "Partition and encrypt" from the format tool menu. \* Set a desired capacity for the encrypted disk. \* Enter a username and password, then confirm the password again. The AMV Convert Tool simplifies file conversion. To use it: \* Install the software by following the on-screen instructions. \* The tool will automatically begin converting selected files after setup is complete. If you encounter any issues during playback, refer to the troubleshooting guide for solutions. Using Your New Player The contents of this manual are subject to change at any time. We reserve the right to update or modify this manual without prior notice.