

Greetings

Thank you very much for purchasing HOMARE. This product was born from the serious consideration of professional violin and viola players in orchestras, who spent years examining the problems with shoulder rests. We pursued the ideal shoulder rest, researching and developing it with the ultimate goal of enabling peak performance during daily practice or long concerts. Whether you are an amateur or a professional, we hope that the rich sound achieved through noise reduction and the expanded range of motion enabled by the research behind this product will allow many music lovers to express the grand universe of music with greater certainty and freedom.

HOMARE CO., LTD.

Safety Precautions

The precautions listed here are provided to ensure the safe and proper use of this product and to prevent injury to you or damage to your instrument. These are important instructions concerning your safety, the safety of your valuable instrument, and the preservation of this product. Please be sure to follow them. Failure to observe these instructions may result in personal injury or property damage.

<About This Product>

- If you find any cracks, breaks, or chips in any part of this product, stop using it immediately. This could cause injury or damage to your instrument.
- Do not stand on this product or place heavy objects on it.
- Do not drop this product or subject it to strong impacts.
- Do not throw, drop, or handle this product roughly. Any use other than attaching it to an instrument is strictly prohibited.
- Do not intentionally heat or cool this product.
- This product uses acrylic material. It will deform if exposed to high temperatures, such as direct sunlight (e.g., inside a car during the day) or near a stove. Use and store it in locations below 50°C (122°F). Conversely, do not use it in extremely cold locations. This may cause the body to deform or break.
- Do not leave it inside a vehicle.
- Do not leave it outdoors in the rain or in windy locations.

<Care and Storage>

- For cleaning, wipe with a soft, dry cloth.
- When cleaning the main unit, never use benzene, thinner, or similar solvents. Also, do not leave vinyl or plastic items on the main unit for extended periods. This may cause cracks or white discoloration on the main unit and could lead to damage.
- Never use chlorine-based cleaners, abrasive cleaners, or strong alkaline cleaners.
- Do not paint, deform, or otherwise modify this product.
- Store in a dry, well-ventilated location with minimal temperature fluctuations.
- If the product gets wet, allow it to dry completely before storing.
- Do not place objects on top of the product during storage. This may cause deformation.

<Product Parts>

- Use only genuine HOMARE parts for each component.
- Do not use any feet (parts attaching to the instrument) other than those included with this product. Doing so may cause injury or damage.
- Do not force screws into place when using this product.
- Do not install the high-pitched side and low-pitched side in reverse.
- The low-pitched side foot (urethane side) is designed to rotate more easily than the high-pitched side. (*Original only)
- Do not extend the low-pitched side screw more than 5mm. This may damage the main unit.
- Do not use aftermarket urethane pads other than those included with this product.

<When Using This Product>

- Always install on the instrument by referring to the HOMARE 3-Step Installation Guide.
- Never use if the instrument is damaged.
- Do not use if you feel any physical discomfort.
- Be mindful of clothing or accessories that may come into contact depending on the position of use.
- Do not use if it does not fit the instrument's size. It may cause damage to the instrument.
- When removing this product, always slide it off parallel to the high-pitched side.
- Do not remove it forcefully or in a hurry.
- Always check that the slider screw is not loose.
- Continuous use may loosen the screw, so check it each time before use.
- Do not store the instrument in its case with this product attached. Always remove this product before placing the instrument in its case.
- Since instruments vary in size, always adjust the size when attaching to a different instrument.
- When lending this product to others, always provide the instruction manual as well.

Warning (!) Prohibited Actions

If the product shows any abnormalities, never attempt to repair or modify it yourself. Once the main body or hardware is deformed, its strength is significantly reduced. Attempting repairs may cause further damage to the main body or hardware, potentially resulting in injury or property damage.

Regarding Initial Defects



We take every precaution in product management. However, should you find any cracks or defects upon purchase, please contact the retailer where you purchased the instrument or use the online email form to discuss the matter.

About After-Sales Service

We also sell urethane pads, slider screws, and feet specifically designed for this product. Please consult your purchasing music store. Please also refer to the official website: www.homare.club

HOMARE Request

Please be sure to keep the receipt or invoice showing the purchase date of this product. In the unlikely event of a manufacturing defect, we cannot process an exchange without the receipt or invoice.



<Material> All components are made from pure domestic materials.
 Body: HOMARE Original V-Acrylic with Makie Finish Made in Japan
 Pad: Custom-made natural rubber Made in Japan
 Slider Metal: Solid Brass Made in Japan
 Slider Screw: Special precision-machined stepped brass with gold plating Made in Japan
 Slider Screw Receiver: V-POM Polycarbonate Made in Japan

Distributor/Manufacturer : **HOMARE CO., LTD.**
104, 6-4-20 Akasaka,
Minato-ku, Tokyo 107-0052, JAPAN
www.homare.club (Official site)
 mail : kataate.homare@gmail.com