

HOW TO USE PUMP2BABY BOTTLE



ASSEMBLE

Assemble the Pump2Baby Bottle as shown.



TIGHTEN

Tighten all connection points to ensure a good seal.



PUMP

Connect bottle to flange and pump until you have some milk to feed baby. To prevent leaking, position capped nipple above bottle.



REMOVE AIR

Position nipple below bottle and tilted upwards. Gently squeeze nipple to remove air inside nipple and tube before feeding.