


☐

I'm not robot


reCAPTCHA

Continue

Holmes 1 touch heater owner's manual

1 DIRECTIVES TOUCHTMHSEATABLED READ AND SAVETHSE IMPORTANT SAFETY INSTRUCTIONS When using electrical appliances, basic safety precautions should always be taken to reduce the risk of fire, electric shock and injury to persons, including the following:1. Read all instructions before using the device.2. To avoid the risk of fire or electric shock, connect the appliance directly to an AC 120V.3 electrical outlet. The heater is hot when used. To avoid burns, DO NOT leave bare skintouch surfaces. If provided, use handles when moving this hethera. Keep combustible materials, such as furniture, pillows, bed linen, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and back.4. DO NOT run the cord under carpeting. DO NOT cover the rope with throwrugs, runners, or the like. Arrange the cable away from the traffic area and where it will not stumble over.5. This heater is not intended for use in bathrooms, laundry rooms and similar indoor location. NEVER locate the heater where it may fall into abathhub or other water container.6. Extreme caution is required when using any heater from, or near children or disabled persons, and whenever the heater is left in operation and unattended.7. Always disconnect the heater when not in use.8. When disconnecting, be sure to pull from the plug and not from the cable.9. DO NOT insert or allow foreign objects to enter any ventilation or outdoor opening, as this may cause electric shock or fire, or the heater.10.DO heater with a damaged cable or plug may not work, or after heater malfunctions, it has fallen or is damaged in any way. Return the appliance to the manufacturer for examination, electrical or mechanical adjustment or repair.11. A heater has hot and bows or firing parts inside. DO NOT use it in areas where gasoline, paint or flammable liquids are used or stored.12.Use the appliance only for intended household use as described in thismanual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons. The use of attachments not recommended or sold by The Holmes Group may cause hazards.13.DO NOT use outdoors.14.To to prevent a possible fire, DO NOT block air intakes or evaporation in any way. DO NOT use it on soft surfaces, such as a bed, where openings can be made blocked.15.To unplug the heater, and hold down the MODE/OFF button for 2 seconds, and then remove the plug from the socket.16.Avoid using an extension cord because the extension cord may overheat and cause a fire hazard. However, if you need to use an extension cord, the cable must be no. 14 AWG minimum size and have no less than 1875 watts.17.If the heater will not work, see specific safety instructions Shut-off.18.DO DO NOT attempt to repair or adjust any electrical or mechanical faults in this unit. This will void your warranty. The interior of the unit does not contain user-maintained components. All maintenance services only by qualified personnel. READ AND SAVETHSE IMPORTANT SAFETY INSTRUCTIONS To take advantage of 1 TouchTMHsorestat to the desired temperature setting. TouchTMHtherat will automatically turn on the heater or turn off depending on the preset comfort level. The com-fort level ranges between 60o and 80o Fahrenheit. Manual instructions.1. Connect the heater to an AC 120V.2 electrical outlet. To start the drive, press the MODE/OFF button once for the HIGH (1500 watt) manual setting. (See fig #1 and #2) 3. Press the button again for the manual LOW (1000 watt) setting. (See fig #1 and #2) 4. To stop the unit, press and hold the button for two seconds or hold down the button until all temperature readings are OFF. Note: The power light will remain on during operation. In ManualMode, only the LOW or HIGH power light will turn on. During season care: Always unplug the heater, before moving or cleaning.1. Carefully wipe the unit with a soft, damp cloth. Please be very careful near the engine and heating elements.2. NeveRuss abrasive or flammable solvents for cleaning the unit.3. After cleaning, be sure to dry the unit completely a cloth or towel. After season care:1. Store the heater in a cool and dry place.2. Holmes recommends that you store the unit in its original box.1. Carefully remove your heater from the box. (Please keep the carton for off-season storage).2. Place the heater on the fixed-level surface.3. Avoid overloading your circuit by not using other high-power devices at the same outlet. At 1500 watts, this unit pumps 12.5 amplifiers. IMAGED 1A. POWER LIGHTS B. B. TEMPERATURE SETTING LIGHTS D. CARRY HANDLE (NOT VISIBLE) ABCDFigure 2A. LIGHTB Temperature SET. LOW ENERGY (1000 WATT)C. HIGH POWER (1500 WATT)D. OPERATION/OFF CONTROL PANEL CLOSE-UPTROUBLESHOOTING If your heater is not working.* Make sure the socket or circuit breaker is working. • Check for obstacles. If you find an obstacle, turn off the heater and unplug the unit. Carefully remove the obstacle and follow the reset instructions. • The thermostat can be very low. Press the MODE/OFF button until the heater restarts. Do not attempt to open or repair the heater. Please see the warranty for service instructions. AUTO SECURITY TERMINATED WITH CERAMIC CONTROLThis is equipped with a patented, technologically advanced, safety system that requires the user to reset the heating device if there is a possible overheating situation. When a possible overheating temperature is reached, the system will automatically turn the heater off. The operation can only continue when the user restores the drive. To reset the heater:1. Unplug the unit.2. Wait 10 minutes for the unit to cool down.3. After 10 minutes, reconnect the unit and operate normally. Note: 1 TouchTMhas memory. TouchTMthercat will remember the previous temperature setting after disabling the unit. However, if the unit is disconnected, 1 TouchTMthereat will be reset and will no longer remember the previous temperature setting. ABCD Holmes Electric Heater User Manual Holmes Electric Heater User Manual Holmes Electric Heater User Manual HOLMES Ceramic Heater HCH4062 OWNER GUIDE Holmes Electric Heater User Manual Holmes Electric User Manual Holmes Oscillating Ceramic Heater Owner Holmes Owner Ceramic Heater Driver HCH4105TG Holmes Electric User Manual Heater HOLMES AccutemTM Ceramic Heater HCH4920 OwnerGuide Holmes Extremely Quiet Ceramic Heater with ViziHeat Owner Guide HCH4953, HCH4954 Holmes Electric Water Heater User Manual Holmes Extremely Quiet Ceramic Heater with ViziHeat Owner Guide HCH4953, HCH4954 Holmes Electric Heater User Manual Holmes Oscillating 1Touch Tower Ceramic Heater Owner Guide Holmes Electric Heater User Manual Holmes Electric Heater User Manual Holmes Electric Regulator Manual Holmes Electric Regulator Manual Holmes Electric Heater Manual Holmes 1 Touch driver of the heater owner HFH5505 the owner holmes guide touch heater hf55551 holmes electric regulator user manual Holmes driver of heating owner Holmes electric heating guide manual holmes electric regulator user manual Holmes portable heater Holmes Electric Heater User Manual Holmes Electric Regulator Manual Holmes Electric Heater User Manual Holmes Tower Quartz Heater Owner HQH305 Holmes Electric Heater User Manual Holmes User Manual Holmes Electric Heater Manual Holmes Tower Quartz Heater Owners Guide HQH369 HOLMES Tower Quartz HQH71 5 ownerGuide HOLMES swinging parabolic heater with remote control HRR848 owner driver holmes ceramic guide owner heater HS4600 Holmes owner portable electric heater Holmes owner driver 1500 watt ceramic heater TCM16 , TCM16SIL Holmes Owner's Guide 1500 Watt Ceramic Heater TCM16, TCM16SIL TCM16SIL