

WIFI advertising vest /backpack APP operation process

Part 1: Download the "LED Space"APP, Connect the WIFI

1. Scan qr code or search and download LED Space App in Google Play and App Store.
2. Plug the backpack into the power supply, turn on the phone WIFI, connect to YS+ device number WIFI hotspot, the initial password: 12345678. (The mobile power supply is 5V2A)
3. Open LED Space APP after successful connection.



Part 2: Function introduction

1、 My LED



Clear program: Click to clear the screen contents

Password setting: Change the WIFI connection password

Rename: Change the name of the display screen

LED light: Adjust the brightness of the screen

2、 Program list



Displays a list of created ads
Ads can be edited and deleted

3、 Partition program




Provides a variety of images /animation and text combination template for users to choose

WiFi advertising vest /backpack APP operation process

Part 2: Function introduction


4、 Message



Send text ads

You can set text font, size, color, animation mode, stop time


5、 Image



Send picture ads

Can set the stop time, animation mode and border

6、 Gif



Send gifs animated


Can set the number of playback

7、 Material



You can choose your favorite pictures and animations in the material

8、 Scrawl



Be creative Free graffiti

Attention:

The best display resolution of pictures and animations is 64 * 64, can be downloaded through Google's browser, or made them through use screenshot software.