

I'm not a bot



Keurig model k145 manual

Keurig model 145. How to know my keurig model. Keurig k145 instruction manual. Keurig k145 manual. Keurig model k145 troubleshooting. Older model keurig instructions.

****Important Safety Precautions**** When using electrical appliances, follow basic safety precautions: 1. Read all instructions before use. 2. Avoid touching hot surfaces; use handles and knobs when available. 3. Ensure proper installation and location of the appliance according to these instructions. 4. Do not use accessory attachments not recommended by the manufacturer. ****Warning for Users and Parents**** - Do not permit children to use the brewer without adult supervision due to the potential for very hot water. - After using a Hot Cocoa K-Cup pack, run a Hot Water Brew Cycle without a K-Cup pack to avoid clogging the Exit Needle. 1. The water heating cycle completes, after which the red HEATING Light will go off. Size options available: 6 oz., 8 oz., or 10 oz. To enjoy your first brew, follow these steps: - Brew a cup of coffee, tea, or hot cocoa using a K-Cup pack. - For an alternative, run hot water through the brewer without a K-Cup pack. 2. For optimal flavor, brew your iced beverages fresh over ice. Method 1: Fill a 16 oz cup with ice and add a K-Cup Menu Controls pack. - Press the BREW Button to start brewing. 3. Regularly clean the brewer's external parts for better performance. - Run the following steps until you complete at least 12 brews using your largest size setting: - Remove water from the Water Reservoir - Check if any filter screens need cleaning - Use a damp, soapy cloth to wipe down surfaces 4. For optimal results, refer to these troubleshooting tips. - Check that the brewer is plugged into an independent power outlet and has been turned on correctly. - If the issue persists, try unplugging and replugging the brewer. Timer feature is not enabled automatically. If the green AUTO-OFF Light is on, press the black AUTO-OFF Button to disable the Auto-Off Timer feature. To add water, completely remove the Water Reservoir and Light, and thoroughly clean red Heating (refer to page 11). Ensure the Light and Small Water Reservoir are filled. *****SECTION 5 Warranty** Incidental costs and expenses resulting from any breach of this warranty, even if foreseeable. Some states or provinces do not allow the exclusion or limitations of incidental or consequential damages, so the above limitation or exclusion may not apply to you depending on the state or province of purchase. *****SECURITY RULES** Using electrical appliances safely: 1. Read all instructions before using. 2. Do not touch hot surfaces. Use handles if available. 3. Install correctly and place in a safe location as instructed before use. 4. TABLE OF CONTENTS Attention: The K-Cup® dosette is pierced by two needles, one above and the other at the bottom of the K-Cup support. To avoid any risk of injury, do not put your fingers into the K-Cup box. *****COMMERCIAL INFUSION SYSTEM ONE CUP K145 OF KEURIG**** — How to use your coffee maker Attention: The water in the K-Cup support during infusion is extremely hot. *****CAFETIERE CONCEPTS AND TIPS**** 1. Connect the coffee maker on a circuit with grounding where it alone is connected. A surge of electrical current with multiple appliances may harm the functioning of your coffee maker. It should be connected separately from other appliances, on its own circuit. 2. Keep your coffee maker in use. Always keep your coffee maker on. We recommend keeping your coffee maker on at all times. *****CAFETIERE K145 OF KEURIG CHARACTERISTICS**** E H O A X W ADD WATER M Z G I C V DESCALE Y T DRAIN BREWER F D U HEATING AUTO-OFF R B POWER P PU N S BREW SH TO BRE W J Q K L *****COMMANDS AND INDICATORS**** A. Water reservoir cover B. Water reservoir C. Locking latches D. Slits for locking latches of the water reservoir E. Handle *****SECTION 1 Preparation and First Infusion**** Important: Do not use your coffee maker Keurig before preparing it for a first time, as instructed below. Note: If the coffee maker has been placed in an area where the temperature was lower than freezing point, let it sit for at least two hours to reach ambient temperature before using. A frozen or very cold coffee maker cannot work properly. Preparation of Your Keurig Coffee Maker: Fig.9 Press the blue brew button (BREW) blinking. Fig.10 The coffee maker will heat the water automatically. This process takes approximately four minutes. During the heating period, the red heating indicator (HEATING) will light up. When the water is hot, the indicator will turn off and the buttons indicating cup sizes will light up. Add K-Cup support (fig.6). Water addition SECTION 1 Preparation and First Infusion: 9 A short pause may precede the start of infusion. The complete infusion process takes about a minute and ends with a burst of air allowing all liquid from the K-Cup to be emptied. 10 Lift the handle and dispose of the used K-Cup. WARNING: The K-Cup is hot. SECTION 2 Iced Beverage Infusion Menu The cold tea and coffee are best when infused over ice. (digital control panel) 1. Fill a 500ml/16oz cup with ice until the rim (do not use glass containers) and place a marked "Brew Over Ice" K-Cup in the coffee maker. Fig.2 Select your desired cup size. SECTION 2 Menu and Indicators SECTION 3 Cleaning and Maintenance Cleaning Exterior Parts: Fig. ADD WATER AUTO-OFF POWER BREW TO BRE It is recommended to regularly clean the exterior parts of the coffee maker. The green indicator light means that automatic shut-off function is activated. When it's off, this function is disabled. 1. Never submerge the coffee maker in water or any other liquid. Fig.11 Release (fig.10). After cleaning, slide the K-Cup support into place using the two notches at the front and click it into position. Rinse thoroughly. Do not dry the inside of the water reservoir with a cloth, as residue may remain. 2. Cleaning the Drip Tray: The drip tray can be cleaned... The cafetière must be emptied and stored in a safe, frost-free area. Ensure it's standing upright to prevent water from leaking from the internal reservoir. # - The cafetière won't turn on: • Check if the cafetière is properly plugged in. • Verify that the power light (POWER) is on. • Reset the circuit breaker if necessary. • Try plugging it into a different outlet. - The cafetière doesn't brew: • Ensure the selector (BREW/DRAIN) is set to the infusion position (BREW). - Water appears at the base of the cafetière. • It's normal for some water (less than 10 ml) to accumulate if the water reservoir has been removed. • Use a cloth or paper towel to absorb the water. • Replace the water reservoir on the cafetière. According to your province or state, some exclusions may not apply. Visit www.keurig.com or call 1-866-901-BREW (2739) for more information about Keurig. Troubleshooting and Maintenance 13Warranty and Support 15User Safety Precautions 16Unpacking and Assembly Instructions 4Important Safety Information 17Product Specifications 18Manufacturer's Address and Warranty Information 19 Pour apprendre plus sur Keurig, vous pouvez visiter le site web www.keurig.com ou composer le 1-866-901-BREW (2739). Votre premier café est prêt à être préparé ! Étape 1 : Si l'éclairage vert POWER est allumé, votre appareil est sous tension. Placez une tasse sur la plaque de la Gouttière. Étape 2 : Lève le manuel et le Conteneur du Pack K-Cup s'ouvrira vers vous (fig. 5). Sélectionnez un pack K-Cup. REMARQUE : Ne retirez pas l'étui en aluminium ou perforez pas le pack K-Cup. Étape 3 : Placez un pack K-Cup dans le Conteneur du Pack K-Cup (fig. 6). REMARQUE : Vous pourriez voir de petites quantités d'eau sortant des Tuyaux et tombant dans le réservoir d'eau pendant cet et la prochaine mise en chauffe – c'est normal. Étape 4 : Lève complètement le manuel, appuyez sur le Bouton BREW (fig. 4) pour commencer une purge. Versez l'eau chaude de la tasse dans l'évier. Étape 5 : Le dispositif peut prendre 15 secondes pour réchauffer de l'eau entre les prises entre les prises. Lorsque l'eau est chauffée, le feu rouge HEATING s'éteindra. Vous êtes maintenant prêt à préparer votre café !