

KINGRINDER LIGHTWEIGHT MANUAL HAND COFFEE GRINDER

- Manual -

P0/P1/P2



WHAT'S IN THE BOX

- Grinder



- Handle



- Rubber sleeve






- Brush



HOW TO OPERATE THE GRINDER?

- 1.Take out the receiver. Put the handle on and hold it to prevent rotation.
- 2.Hold the handle, and rotate the spin dials clockwise till tightened.
- 3.Rotate the spin dials counterclockwise to the grinding click numbers.
(Please refer to the advised grinding clicks below.)
- 4.Put the receiver on and take the handle out. Put 20g coffee beans into the grinder.
- 5.Put the handle on and start to grind.



RECOMMENDED GRINDER SETTINGS

※**ONE CIRCLE IS EQUIVALENT TO 30CLICKS.**

Brewing methods	P0	P1	P2
Espresso	Not recommended	10~20clicks	
Moka pot AeroPress	30~40clicks		
Pour-Over	45~60clicks		
French Press	70~80clicks		

HOW TO CLEAN THE GRINDER?

1. Take out the receiver and put the handle on the grinder.
2. Hold the handle, and rotate the spin dials counterclockwise till it is completely rotated down.
3. Take the components out. (Showed as the pictures.)
4. Use the air blower and the brush to clean the residue coffee powder.
5. To reassemble the components in sequence.



PRECAUTIONS:

1. The entire grinder **should not be washed water**. Please use the provided brush or air blower for cleaning.
2. Please do not turn the handle when the scale is **at zero or when it's below 8 clicks**, as this could cause damage to the burr.
3. For precision reasons, the exterior burr and the central axis should not be dismantled. **Do not forcefully disassemble using tools**.
4. Please refrain from grinding items other than coffee beans. Additionally, **do not grind unroasted beans** that have not undergone the roasting process.
5. The product's outer casing is made of molded plastic and may have seams and slight traces, which are normal occurrences.