


# KINGGrinder



# KINGGrinder

## The Exterior Adjustment of K4 and K6 manual coffee grinder KINGrinder Manual - Exterior Adjustment

### How to operate the grinder?

1. Rotate anti-clockwise to the desired grind setting from zero.
2. Take out the **handle** and the **PC lid**, load 30~35g of coffee beans into it.
3. Put on the **handle** and the **PC lid** then spin the **handle** clockwise till it has done.

### How to install the PC lid? (There are method A and method B)

- A. Default setting: the **PC lid** and the **handle** are separate-able for grinding (drill-grinding is applicable).
- B. Attach the **PC lid** and the **handle**: Take out the **Black O-ring** - Place the **White O-ring** into the groove.

### How to adjust grind setting?

1. Rotate the **adjustment nut** clockwise till tightened. The corresponding number is zero and the number on the **adjustment nut** may not be the same as the number of clicks from the grind setting.
2. Rotate the **adjustment nut** anti-clockwise from the zero to your grind size.
3. Rotate the **adjustment nut** anti-clockwise for a coarser grind and vice versa.

KINGGrinder	K4	K6
Extra Fine	15~50	15~25
Fine	50~60	25~60
Medium-Fine	60~90	
Medium	90~120	
Coarse	150	

## How to disassembling the grinder?

1. Rotate the **adjustment nut** anti-clockwise for a coarser grind before dismantling the grinder.
2. Hold down the **burr set** with a hand and remove the **circlip** with another hand.
3. Take out the components in order. The **burr set** (attached with the central shaft), the **bearing cover** and the **spring** from the **burr set**. Then the **top bearing cover** and the **top bearing** from the above.

## How to assembling the grinder?

1. Put on the components in order. The **spring** and the **bearing cover** and then put the **burr set** back to the grinder.
2. Hold down the **burr set** with a hand and put on the **top bearing** and the **top bearing cover**. There are two shapes of the **top bearing cover**: flat design and curve design. The curve design shape of the **top bearing cover** facing upward.
3. Slide the **circlip** onto the curve design shape of the **top bearing cover** with another hand.

## What's to do and not to do?

- Cleansing with a brush.
- Don't wash the grinder with water.
- Don't disassemble the **burr set unit** and the **adjustment nut**.

@: [hello@kingrinder.com](mailto:hello@kingrinder.com)

Website: [www.kingrinder.com](http://www.kingrinder.com)

Instagram: [KINGrinder](https://www.instagram.com/KINGrinder)

Linktree: [KINGrinder](https://www.kingrinder.com)

# KINGrinder