



Performance Solution Scenario

PAA Access Consultants

www.paaaccess.au

projects@paaaccess.au

1300 860 009

Ambulant Toilet Width

Identified Design Issue

Existing conditions result in a clearance of 890mm, instead of 900mm to 920mm.

Departure from Deemed-to-Satisfy Provisions

The existing walls are structural and would require significant work to increase the toilet to a 900mm width.

The Performance Solution

Using a 30mm or 32mm grabrail will help to maximise the clearance in the toilet area and maintain the relationship between the pan location and each grabrail.

This example is a hypothetical scenario and must not be used for any specific project.

Assessments must be tailored for each project.

Contact us to learn more. We are experts at preparing Performance Solution Reports.



Disclaimer: This publication provides general information only and does not constitute legal, certification or project-specific advice. Requirements may vary between projects and change over time. Always verify the current NCC, legislation and applicable Australian Standards, and obtain project-specific advice where required.

Images: PICCI-supplied imagery is licensed to the publisher and may not be reproduced or modified without permission. Third-party content remains subject to its applicable licence. Images are illustrative unless stated otherwise