

Fringer Nikon F - Fujifilm X smart adapter

firmware release notes

Applies to:

FR-FTX1 (Fringer NF-FX)

2021/1/14

Version 1.10

1. Added following lenses to the tested and optimized lens list:

- 1) AF-S NIKKOR 600mm f/4G ED VR *
- 2) AF-S NIKKOR 600mm f/4G ED VR + 1.4X *
- 3) AF-S NIKKOR 600mm f/4G ED VR + 1.7X *
- 4) AF-S NIKKOR 600mm f/4G ED VR + 2X *
- 5) AF-S NIKKOR 500mm f/4G ED VR
- 6) AF-S NIKKOR 500mm f/4G ED VR + 1.4X
- 7) AF-S NIKKOR 500mm f/4G ED VR + 1.7X
- 8) AF-S NIKKOR 500mm f/4G ED VR + 2X
- 9) AF-S NIKKOR 300mm f/2.8G ED VR II
- 10) AF-S NIKKOR 300mm f/2.8G ED VR II + 1.4X
- 11) AF-S NIKKOR 300mm f/2.8G ED VR II + 1.7X
- 12) AF-S NIKKOR 300mm f/2.8G ED VR II + 2X
- 13) AF-S NIKKOR 80-200mm f/2.8D
- 14) AF-S NIKKOR 80-200mm f/2.8D + 1.4X
- 15) AF-S NIKKOR 80-200mm f/2.8D + 1.7X
- 16) AF-S NIKKOR 80-200mm f/2.8D + 2X
- 17) AF-S NIKKOR 300mm f/4D IF-ED
- 18) AF-S NIKKOR 300mm f/4D IF-ED + 1.4X
- 19) SIGMA 150-600mm F5-6.3 DG OS HSM S014
- 20) SIGMA 150mm f/2.8 EX DG HSM APO Macro
- 21) SIGMA 10-20mm f/4-5.6 EX DC HSM

***Be noted:** Due to the limited power supply of the small mirrorless cameras, AF-S600/4G VR may drain too much current and work unstable. If that happens, please turn off VR to save power consumption.

2. Fixed compatible issues with some old Nikon AF and AF-D lenses. Following lenses were not compatible and work normally (MF only) now. (Although not tested, yet, more Nikon AF and AF-D lenses should be compatible now)

- 1) AF Fisheye-Nikkor 16mm f/2.8D
- 2) AF Nikkor 85mm f/1.8D
- 3) AF Nikkor 85mm f/1.4D
- 4) AF Micro Nikkor 105mm f/2.8D
- 5) AF DC Nikkor 135mm f/2D
- 6) AF Nikkor 24mm f/2.8

- 7) AF Nikkor 50mm f/1.8
- 8) AF Nikkor 35-135/3.5-4.5
- 9) AF Nikkor 75-300mm f/4.5-5.6
- 3. Increased AF speed in movie mode for the following lenses:
 - 1) AF-P NIKKOR 70-300mm f/4.5-5.6E ED VR
 - 2) AF-P DX NIKKOR 70-300mm f/4.5-6.3G ED VR
 - 3) AF-S DX NIKKOR 16-80mm f/2.8-4E ED VR

[Click here to understand how to upgrade.](#)

Version 1.00

Initial version

You need a PC or MAC and a USB Micro B cable to upgrade the adapter.

1. Connect the adapter to your computer.
2. Find a new driver named “FRINGER” and copy new firmware to it.
3. Wait for 20 seconds. The adapter will disconnect itself from the computer and reconnect. If it doesn’t reconnect automatically, you may disconnect the USB cable and reconnect it manually.
4. Check installed firmware version (VERSION.TXT on the adapter)

For example:

Before upgrade:

```
FBL: NFFX V1.1
Fringer adapter product: NF-FX
Version: 0.80
Internal Version: 20.11.15.1
```

After upgrade:

```
FBL: NFFX V1.1
Fringer adapter product: NF-FX
Version: 1.00
Internal Version: 20.12.12.1
```

Troubleshooting:

Some of the cables in the market are for charging only and not suitable for data transfer. Thus, if you can’t find the “FRINGER” drive when adapter is connected to the computer, **check your cable!**

You may also read the adapter’s firmware version by Fujifilm’s method, i.e. press and hold DISP button before power on the camera. The “Lens version” on the screen is actually the adapter’s firmware version.

